
Husqvarna

Illustrated Parts List	2000-10
	I0002016

LT 1238 A

954567024




Repair Parts Manual

Ride Mower


TRACTOR - - MODEL NUMBER (LT1238) LT1238A, PRODUCT NO. 954 56 70-24

SCHEMATIC



NOTE

YOUR TRACTOR IS EQUIPPED WITH A SPECIAL ALTERNATOR SYSTEM. THE LIGHTS ARE NOT CONNECTED TO THE BATTERY, BUT HAVE THEIR OWN ELECTRICAL SOURCE. BECAUSE OF THIS, THE BRIGHTNESS OF THE LIGHTS WILL CHANGE WITH ENGINE SPEED. AT IDLE THE LIGHTS WILL DIM. AS THE ENGINE IS SPEEDED UP, THE LIGHTS WILL BECOME THEIR BRIGHTEST.



IGNITION SWITCH

POSITION	CIRCUIT	"MAKE"
OFF	M+G+A1	NONE
RUN/LIGHT	B+A1	A2+L
RUN	B+A1	NONE
START	B + S + A1	NONE


WIRING INSULATED CLIPS

NOTE: IF WIRING INSULATED CLIPS WERE REMOVED FOR SERVICING OF UNIT, THEY SHOULD BE REPLACED TO PROPERLY SECURE YOUR WIRING.

REPAIR PARTS

TRACTOR - - MODEL NUMBER (LT1238) LT1238A, PRODUCT NO. 954 56 70-24

ELECTRICAL



REPAIR PARTS

TRACTOR - - MODEL NUMBER (LT1238) LT1238A, PRODUCT NO. 954 56 70-24

ELECTRICAL


KEY NO.	PART NO.	DESCRIPTION
1	532144925	Battery 12 Volt 25 Amp
2	874760412	Bolt Hex Hd 1/4-20unc X 3/4
8	532156417	Case Battery Mech Hiinge
16	532153664	Switch Interlock Push-In
21	532166181	Harness Asm Light W/4152j
22	532004152	Bulb Light #1156
24	532124780	Cable Battery 6 Ga 11"red
25	532146147	Cable Battery
26	532175158	Fuse
27	873510400	Nut Keps Hex 1/4-20 Unc
28	532124773	Cable Ground 6 Ga 12"black
29	532121305	Switch Plunger Nc Gray
30	532175566	Switch Ign
33	532140401	Key Ign
40	532170217	Harness Ign
41	871110408	Bolt Blk Fin Hex 1/4-20
42	532131563	Cover Terminal Red
43	532175141	Solenoid
48	532140844	Adapter Ammeter
52	532141940	Protection Wire Loop

NOTE: All component dimensions given in U. S. inches 1 inch = 25.4 mm.

REPAIR PARTS

TRACTOR - - MODEL NUMBER (LT1238) LT1238A, PRODUCT NO. 954 56 70-24

CHASSIS



REPAIR PARTS

TRACTOR - - MODEL NUMBER (LT1238) LT1238A, PRODUCT NO. 954 56 70-24

CHASSIS


KEY NO.	PART NO.	DESCRIPTION
1	532169831	Chassis
2	532169061	Drawbar, Stretch
3	817060612	Screw 3/8-16 x 3/4
5	532155272	Bumper, Hood/Dash
6	532155923	Saddle
8	532155138	Clip Retainer Slide-On
9	532171796	Dash
10	872140608	Bolt, Carriage 3/8-16 x 1
11	532155927	Panel Dash LH
12	532145660	Clip Tinnerman Grille P.L
13	532173025	Panel Slkscr Dash RH
15	874180512	Screw Mach TRHD 5/16-18uncx3/4
16	873510500	Nut Keps 5/16-18 Unc
17	532162237	Hood
18	532126938	Bumper Hood
24	874780616	Bolt Fin Hex 3/8-16unc X 1 Gr. 5
25	819131312	Washer 13/32 X 13/16 X 12 Ga
26	873800600	Nut Lock Hex w/Ins 3/8-16 Unc
28	532143499	Grille/Lens Asm.
29	532168154	Lens Grille Private Label
30	532177025	Fender
31	532136619	Bracket Fender Repl 109873x
33	532153539	Footrest Pnt LH Perf
34	532153538	Footrest Pnt RH Perf
35	872110606	Bolt Rdhd Sht Sqnk 3/8-16 X3/4
37	817490508	Screw Thdrol 5/16-18 x 1/2 TYT
38	532169834	Bracket Asm. Pivot Mower Rear
51	873800400	Nut Lock W/Insert 1/4-20unc
52	819091416	Washer 9/32 x 7/8x16 Ga.
53	532144697	Bracket Grille Lh
54	532161464	Screw Hex 8-18 x 7/8
55	532144696	Bracket Grille Rh
57	874780412	Bolt Fin Hex 1/4-20 unc x .75
58	532150127	Duct Air Engine PL/LT
145	532156524	Rod Pivot Chassis/Hood
206	532170165	Bolt Shoulder 5/16-18
208	817670608	Screw Thdrol 3/8-16 x 1/2
209	817000612	Screw Hex Wsh Thdrol 3/8-16
212	532156229	Insert Lens Reflect
---	532005479	Plug Button Blk 359 Dia Choke

NOTE: All component dimensions given in U.S. inches
1 inch = 25.4 mm.

REPAIR PARTS

TRACTOR - - MODEL NUMBER (LT1238) LT1238A, PRODUCT NO. 954 56 70-24

DRIVE



REPAIR PARTS

TRACTOR - - MODEL NUMBER (LT1238) LT1238A, PRODUCT NO. 954 56 70-24

DRIVE


KEY NO.	PART NO.	DESCRIPTION
1	- - - - - - - - -	Transaxle (See Breakdown) Peerless 206-545C
2	532146682	Spring Return Brake T/a Zinc
3	532123666	Pulley Transaxle 18" tires
4	812000028	Ring Retainer # 5100-62
5	532121520	Strap Torque 30 Degrees
6	817060512	Screw 5/16-18 x 3/4
8	532165619	Rod Shifter Fender Adj Lt
10	876020416	Pin Cotter 1/8 x 1 Cad
11	532105701	Washer Plate Shf 388 Sq Hole
13	874550412	Bolt 1/4-28 Unf Gr 8 W/Patch
14	810040400	Washer Lock Hvy Helical 1/4
16	873800500	Nut Lock
18	874780616	Bolt, Fin Hex 3/8-16 UNC x 1 Gr. 5
19	873800600	Nut Lock 3/8-16 Unc
21	532106933	Knob
22	532130804	Rod Brake Blk Zinc 26 840
24	873350600	Nut Hex Jam 3/8-16 Unc
25	532106888	Spring Rod Brake 2 00 Zinc
26	819131316	Washer 13/32 X 13/16 X 16 Ga
27	876020412	Pin Cotter 1/8 X 3/4 Cad
28	532145204	Rod Brake Parking LT/YT
29	532071673	Cap Brake Parking
30	532174973	Bracket Mtg Transaxle
31	532127275	Keeper Belt LH LT 14 Ga
32	874760512	Bolt Hex Hd 5/16-18unc X 3/4
34	532155071	Shaft Asm Pedal Foot
35	532120183	Bearing Nylon Blk 629 Id
36	819211616	Washer 21/32 X 1 X 16 Ga
37	532124963	Pin Roll 3/16 X 1"
38	532131494	Pulley Idler Flat
39	874760644	Bolt Fin Hex 3/8-16unc X 2-3/4
40	532124965	Spacer Split 395 X 59 Bzp
41	532165838	Keeper Belt Retainer Idler
42	819131312	Washer 13/32 X 13/16 X 12 Ga
47	532127783	Pulley Idler V Groove Plastic
48	532154407	Bellcrank Asm
49	532123205	Retainer Belt Style Spring
50	874760624	Bolt Hex Hd 3/8-16unc X 1-1/2
51	873680600	Nut Crownlock 3/8-16 Unc
52	873680500	Nut Crownlock 5/16-18 Unc
53	532105710	Link Clutch
55	532105709	Spring Return Clutch 6 75
56	874760620	Bolt Fin Hx 3/8-16 X 1-1/4
57	532130801	V-Belt Ground Drive
58	532127274	Keeper Belt RH LT Pnt/zinc 16g
59	532169691	Keeper Belt Span Ctr
61	817060612	Screw 3/8-16 x 3/4
62	532124872	Cover Pedal Blk Round
63	532140186	Engine Pulley LT/YT
64	871170764	Bolt Hex
65	810040700	Washer Lock Hvy Hlcl Spr 7/16
66	532154778	Keeper Belt Engine Foolproof
70	532134683	Guide Belt Mower Drive RH
72	819132012	Washer 13/32 X 1-1/4 X 12 Ga
74	532137057	Spacer Axle
75	532121749	Washer 25/32 X 1 1/4 X 16 Ga
76	812000001	E-ring #5133-75
77	532123583	Key Square 2 0 X 1845/ 1865
78	532121748	Washer 25/32 X 1-5/8 X 16 Ga
79	532125096	Key Woodruff
80	532131486	Arm Shift
81	532165594	Shaft Asm Cross Tapered 20"t
82	532123782	Spring Torsion T/a
83	819171216	Washer 17/32 X 3/4 X 16 Ga
84	532166228	Link Transaxle
85	532150360	Nut Lock Center 1/4 - 28 FNTHD
89	532177031	Console Shift STLT
90	532124346	Nut Self-thd Wsh-hd 1/4 Zinc
96	532124788	Retainer Spring
112	819091210	Washer 9/32 x 3/4 x 10 Ga.
113	532127285	Strap Torque Lh
116	872110610	Bolt Rdhd Sq Neck 3/8-16 x 1.25
145	874490540	Bolt Hex 5/16-18 Gr. 5
150	532165850	Bushing Bellcrank Grd. Drive
151	819133210	Washer 13/32 x 2 x 10
156	532166002	Washer Srrted 5/16 ID x 1.125
158	532165589	Bracket Shift Mount
159	532165494	Hub Tapered Flange Shift lt
161	872140406	Bolt Rdhd Sqnk 1/4-20 x 3/4 Gr 5
162	873680400	Nut Crownlock 1/4-20 Unc
163	874780416	Bolt Hex Fin 1/4-20 Unc x 1 Gr 5
164	819091010	Washer5/8 x .281 x 10 Ga
165	532165623	Bracket Pivot Lever
166	532166880	Screw 5/16-18 x 5/8
168	532165492	Bolt Shoulder 5/16-18 x .561
169	532165581	Plate Fastening Lt
171	817490608	Screw Thdrol 3/8-16 x 1/2
197	532169613	Nyliner, Snap - in
198	532169593	Washer, Nyl.
202	872110612	Bolt, Carriage 3/8 - 16 x 1

NOTE: All component dimensions given in U.S. inches
1 inch = 25.4 mm

REPAIR PARTS

TRACTOR - - MODEL NUMBER (LT1238) LT1238A, PRODUCT NO. 954 56 70-24

STEERING



REPAIR PARTS

TRACTOR - - MODEL NUMBER (LT1238) LT1238A, PRODUCT NO. 954 56 70-24

STEERING


KEY NO.	PART NO.	DESCRIPTION
1	532124415	Wheel Steering
2	532154427	Axle Asm
3	532169840	Spindle Asm LH
4	532169839	Spindle Asm RH
5	532124931	Bearing Race Thrust Harden
6	532121748	Washer 25/32 X 1-5/8 X 16 Ga
7	819272016	Washer 27/32 X 1-1/4 X 16 Ga
8	812000029	Ring Klip #t5304-75
9	532124937	Bearing Col Strg Blk
10	532169832	Link Drag
11	810040600	Washer Lock Hvy Hlcl Spr 3/8
13	532136518	Spacer earing Axle Front
15	532145212	Hexflange Lock
17	532156546	Shaft Asm Strg
18	532057079	Washer Thrust 515x 750x 033
19	532160395	Support Shaft
22	532165857	Screw Hex Wsh Hd Torx
23	532165851	Shaft Asm Pittman
25	532154406	Bracket Steering
26	532126847	Bushing Link Drag Blk LR
27	532136874	Gear Sector
28	819131416	Washer 13/32 X 7/8 X 16 Ga
29	817060612	Screw 3/8-16 x 3/4
30	876020412	Pin Cotter 1/8 X 3/4 Cad
32	532130465	Rod Tie Wire Form 19 75 Mech
36	532155099	Bushing Strg 5/8 Id Dash
37	532152927	Screw
38	532124416	Cap Wheel Steer
39	819133812	Washer 13/32 x 2-3/8 x 12 Ga.
40	532124701	Nut Lock Center 3/8-24un
41	532100711	Adaptor Wheel Strg
42	532169634	Boot Dash Mtl Steering Blk
43	532121749	Washer 25/32 X 1 1/4 X 16 Ga
44	532153720	Extension Steering
46	532121232	Cap Spindle Fr Top Blk
47	532124836	Fitting Grease
51	873800500	Nut Lock Hex W/Ins 5/16-18
54	874780520	Bolt Fin Hex 3/8-16unc x 1-1/4
62	532167902	Kit Steering Assembly Service
63	874780616	Bolt Fin Hex 3/8-16unc x 1 Gr.5
65	532160367	Spacer Brace Axle
66	532154404	Bearing Arm Pittman
67	872140618	Bolt Fin Hex 5/8-11 unc x 2-3/4
68	532169827	Brace Axle
79	819132012	Washer 13/32 x 1 1/4 x 12 Ga.
80	874950612	Bolt Hex 3/8-16 x 3/4
82	532169835	Bracket Susp Chassis Front
85	532133835	Fastener Christmas Tree

NOTE: All component dimensions given in U.S. inches
1 inch = 25.4 mm.

REPAIR PARTS

TRACTOR - - MODEL NUMBER (LT1238) LT1238A, PRODUCT NO. 954 56 70-24

ENGINE



REPAIR PARTS

TRACTOR - - MODEL NUMBER (LT1238) LT1238A, PRODUCT NO. 954 56 70-24

ENGINE


KEY NO.	PART NO.	DESCRIPTION
1	532170551	Control Th/ch Flag
2	817720410	Screw Hex Thd Cut 1/4-20x5/8 T
3	- - - - - - - -	Engine, B&S 289707 (Order parts from engine manufacturer)
4	532137348	Muffler Exhaust B&S Lc
13	532165291	Gasket Eng 1 313 Id Tin Plated
14	532148456	Tube Drain Oil Easy
16	811050600	Washer Lock Ext Tooth 3/8
23	532169837	Shield BRN/DBR Guard
29	532137180	Kit Spark Arrestor (Flat Scrn)
31	532109202	Tank Fuel Front
32	532140527	Cap Asm Fuel
33	532123487	Clamp Hose
37	532137040	Line Fuel 20"
38	532148315	Plug Drain Oil Easy
40	532124028	Bushing Snap Nyl Blk Fuel Line
44	817670412	Screw Thdrol 1/4-20 x 3/4
45	817000612	Screw Hex Wsh Thdrol 3/8-16
46	819091416	Washer 9/32 X 7/8 X 16 Ga
62	810040500	Washer Lock Hvy Hlcl Spr
72	871070512	Screw Hexcap 5/16-18 x 3/4
78	817060620	Screw 3/8-16 x 1-1/4
81	873510400	Nut Keps Hex 1/4-20 Unc

NOTE: All component dimensions given in U.S. inches
1 inch = 25.4 mm

REPAIR PARTS

TRACTOR - - MODEL NUMBER (LT1238) LT1238A, PRODUCT NO. 954 56 70-24

SEAT




KEY NO.	PART NO.	DESCRIPTION
1	532130875	Seat
2	532140551	Bracket Seat Pivot
3	871110616	Bolt Hex 3/8 - 16 X 1
4	819131610	Washer 13/32 X 1 X10Ga.
5	532145006	Clip Push-In Hinged
6	873800600	Nut Lock Hex w/Ins 3/8 - 16
7	532124181	Spring Seat Cprsn 2 250 Blk Zi
8	817000616	Screw 3/8-16 x 1.5
9	819131614	Washer 13/32 X 1 X 14 Ga
10	532174894	Pan Pnt Seat (Blk)
12	532121246	Bracket Pnt Mounting Switch
13	532121248	Bushing Snap Blk Nyl
14	872050412	Bolt Rdhd Sht Nk 1/4 - 20 X 1 -1/2
15	532134300	Spacer Split .28 X .96
16	532121250	Spring Cprsn
17	532123976	Nut Lock 1/4 Lge Flg
21	532171852	Bolt Shoulder 5/16-18 Unc-2A
22	873800500	Nut Lock Hex w/Ins 5/16 - 18
23	871110814	Bolt Hex Black
24	819171912	Washer 17/32 X 1-3/16 X 12 Ga
25	532127018	Bolt Shoulder 5/16-18 X .62
26	810040800	Washer Lock Hvy Hlcl Spr 1/2

NOTE: All component dimensions given in U.S. inches 1 inch = 25.4 mm.

REPAIR PARTS

TRACTOR - - MODEL NUMBER (LT1238) LT1238A, PRODUCT NO. 954 56 70-24


DECALS



KEY NO.	PART NO.	DESCRIPTION
1	532101892	Decal, Clutch/Brake Eng/Fr
3	532170839	Decal, Engine HP
4	532170563	Decal Warning
6	532157140	Decal, Fender Danger English
7	532175854	Decal Ins Str Wh
9	532176822	Decal Fender
12	532176769	Decal, Hood RH
14	532176770	Decal, Hood LH
15	532145005	Decal, Caution, Battery
16	532157163	Decal, Oper Sdl P/L Gear Dr Eng
17	532136832	Decal, V-Belt Sch.

KEY NO.	PART NO.	DESCRIPTION
- -	532138311	Decal, Handle Lft Height Adj.
- -	532176577	Manual, Owner's English
- -	532176578	Manual, Owner's French
Available accessories not included with mower:		
- -	C38	Grass Catcher
- -	MK38	Mulch Kit w/Blades
- -	LSB42	42" Snow Blower
- -	LC05	Wheel Weights
- -	LBD48	48" Snow Blade
- -	CH11	Tire Chains

WHEELS & TIRES




KEY NO.	PART NO.	DESCRIPTION
1	532059192	Cap, Tire valve
2	532065139	Stem, Valve
3	532106222	Tire, Front
4	532059904	Tube, Front (Service item only)
5	532138336	Rim assembly, 6"front
6	532124957	Fitting, Grease (Front wheel only)
7	532124959	Bearing, Flange (Front wheel only)
8	532138337	Rim assembly, 8" rear
9	532124635	Tire, Rear
10	532124926	Tube, Rear (Service item only)
11	532175039	Cap, Hub Axle
- -	532144334	Sealant, Tire (10 oz. Tube)

NOTE: All component dimensions given in U.S. inches
1 inch = 25.4 mm

REPAIR PARTS

TRACTOR - - MODEL NUMBER (LT1238) LT1238A, PRODUCT NO. 954 56 70-24

MOWER LIFT



REPAIR PARTS

TRACTOR - - MODEL NUMBER (LT1238) LT1238A, PRODUCT NO. 954 56 70-24

MOWER LIFT


KEY NO.	PART NO.	DESCRIPTION
1	532159460	Wire Asm Inner/Sprg w/plunger
2	532159471	Shaft Asm Lift RH
3	532105767	Pin Groove 1 500 Zinc
4	812000002	E Ring #5133-62
5	819211621	Washer 21/32 X 1 X 21 Ga
6	532120183	Bearing Nylon Blk 629 Id
7	532109413	Grip Handle Bicycle Matte Blk
8	532124526	Button Plunger Black
11	532139865	Link Lift LH Fixed Length
12	532139866	Link Lift RH Fixed Length
13	532124670	Retainer Spring
15	532173288	Link Front
16	873350800	Nut Jam Hex 1/2-13 Unc
17	532130171	Trunnion Blk Zinc
18	873800800	Nut Lockw/Wsh 1/2-13 Unc
19	532139868	Arm Suspension Rear
20	532163552	Retainer, Spring
31	532169865	Bearing Pvt Lift
32	873540600	Nut Crownlock 3/8-24

NOTE: All component dimensions given in U.S. inches
1 inch = 25.4 mm.

REPAIR PARTS

TRACTOR - - MODEL NUMBER (LT1238) LT1238A, PRODUCT NO. 954 56 70-24

MOWER DECK



REPAIR PARTS

TRACTOR - - MODEL NUMBER (LT1238) LT1238A, PRODUCT NO. 954 56 70-24

MOWER DECK

KEY NO.	PART NO.	DESCRIPTION
1	532170280	Mower Housing Assembly
2	872140506	Bolt Carriage 5/16-18 x 3/4
3	532138017	Bracket Asm Fr. Sway Bar
4	532169970	Bracket Deck Sway Bar 38"/42"
5	532124670	Retainer Spring
6	532130832	Arm, Suspension, Rear
8	532850857	Bolt 3/8-24 x 1.25 Grade 8
9	810030600	Washer, Lock 3/8
10	532140296	Washer, Hardened
11	532138497	Blade Mower
13	532137645	Shaft Assembly, Mandrel, Vented (Includes Key Number 6)
14	532128774	Housing, Mandrel, Vented
15	532110485	Bearing, Ball, Mandrel
16	532140329	Stripper, Vented Mower Deck
19	532132827	Bolt, Shoulder
21	873680500	Nut
23	532137607	Bracket, Mower Deflector
24	532105304	Cap, Sleeve
25	532123713	Spring, Torsion, Deflector
26	532110452	Nut, Push
27	532175943	Shield, Deflector
28	819111016	Washer 11/32 x 5/8 x 16 Gauge
29	532106735	Rod, Hinge
30	532157722	Screw Thdrol. Washer Head
31	532129963	Washer, Spacer
32	532153532	Pulley, Mandrel
33	532137266	Nut, Toplock 9/16
36	532131494	Pulley, Idler, Flat
40	73680600	Nut, Crownlock 3/8-16 Unc
45	532124788	Retainer
53	532130840	Brake Assembly
54	532133943	Washer, Hardened
55	532133840	Idler Arm Assembly
56	532165723	Spacer, Retainer
67	532106932	Knob
68	532144200	V-Belt, 42" Mower
69	876020312	Pin, Cotter 3/32 x 3/4
86	532125074	Runner, LH
87	532128772	Runner, RH
88	819111216	Washer 11/32 x 3/4 x 16 Ga
89	819131612	Washer 13/32 x 1 x 12 Ga.
107	532133502	Spacer Retainer
108	532133503	Stiffener, Idler Arm
109	874760640	Bolt, Hex Hd 3/8-16 x 2-1/2
110	532142587	Upstop Deck Front 38"
113	817060512	Screw 5/16-1/ x 3/4
122	532131289	Rod, Brake LH
123	532169971	Rod, Brake RH
146	532165891	Bolt Carriage Idler
148	532169022	Spring Return Idler
149	532165898	Retainer Spring Yellow
150	819091216	Washer 9/32 x 3/4 x 16 Ga.
151	532169670	Bracket Clutch Cable
152	532172758	Clutch Cable 38"/46"
153	532169674	Washer Flat 3/8" Type B
154	532169675	Spring Retainer
155	532169671	Spring Retention LVR CLTCH CAB
156	532169672	Spacer Clutch Cable
157	532169669	Rod Clutch Cable 3/8"
158	817720410	Screw Hex Thd Cut 1/4-20 x 5/8
- -	532130794	Mandrel Assembly (Includes Key Numbers 12-15, 17-19, 31 and 33)
- -	532170317	Mower Deck, Complete

NOTE: All component dimensions given in U.S. inches
1 inch = 25.4 mm