
# ILLUSTRATED PARTS LIST


## MFG. ID NO. 96051003001
## CUSTOMER CATALOG NO. CTH194
## PRODUCT NO. 960 51 00-30

47




# TRACTOR - MODEL NO. CTH194 (96051003001), PRODUCT NO. 960 51 00-30

## DECALS 27




| KEY NO. | PART NO. | DESCRIPTION |
|---|---|---|
| 1 | 581 57 83-01 | Decal Warning Sym. CE |
| 2 | 581 57 97-01 | Decal Warning Eng. Sym. |
| 4 | 586 04 97-01 | Decal Replacement |
| 5 | 581 57 84-01 | Decal, Lower Dash |
| 6 | 581 72 41-01 | Decal 100 DBA |
| 7 | 581 62 73-01 | Decal Hood |
| 8 | 532 44 67-75 | Decal Side Panel |
| 9 | 581 57 98-01 | Decal Warning Service/Fire |
| 11 | 581 57 91-01 | Decal Mower Cut Finger Symbol |
| 14 | 581 57 96-01 | Decal Chassis Hot Muffler |
| 21 | 532 44 11-89 | Decal Belt Schematic |
| 22 | 532 44 51-02 | Decal, Battery |
| 23 | 532 44 46-19 | Decal, Bypass |
| 24 | 532 44 54-93 | Decal, Info/Warning |
| - - | 532 44 14-09 | Pad, Footrest Pad LH |
| - - | 532 44 14-10 | Pad, Footrest Pad RH |
| - - | 581 06 99-40 | Manual Operator's (Euro) |

## WHEELS AND TIRES





| KEY NO. | PART NO. | DESCRIPTION |
|---|---|---|
| 1 | 532 05 91-92 | Cap Valve Tire |
| 2 | 532 06 51-39 | Stem Valve |
| 3 | 532 13 83-36 | Rim Front |
| 4 | 532 05 99-04 | Tube Front (Service Item Only) |
| 5 | 532 10 62-22 | Tire Front 15 x 6.0-6 |
| 6 | 532 12 49-57 | Fitting Grease (Front Wheel Only) |
| 7 | 532 12 49-59 | Bearing Flange (Front Wheel Only) |
| 8 | 532 17 50-39 | Cap Axle Blk 1 50 x 1 00 |
| 9 | 532 42 05-31 | Tire R.TS 18 x 9.5-8.C.Ser. |
| 10 | 532 12 49-26 | Tube Rear (Service Item Only) |
| 11 | 532 13 83-37 | Rim Asm 8" Rear |
| - - | 532 14 43-34 | Sealant, Tire (10 oz. Tube) |

**NOTE:** All component dimensions given in U.S. inches
1 inch = 25.4 mm

# TRACTOR - MODEL NO. CTH194 (96051003001), PRODUCT NO. 960 51 00-30

## SCHEMATIC 38

SCH19









IGNITION SWITCH

| POSITION | CIRCUIT "MAKE" |
|---|---|
| OFF | M+G+A1 |
| RUN/OVERRIDE | B+A1 |
| RUN | B+A1 L+A2 |
| START | B + S + A1 |



CHASSIS HARNESS
CONNECTOR (C1)
(MATING SIDE)



DASH HARNESS
CONNECTOR (C1)
(MATING SIDE)


WIRING INSULATED CLIPS
NOTE: IF WIRING INSULATED CLIPS WERE REMOVED FOR SERVICING OF UNIT, THEY SHOULD BE RE-INSTALLED TO PROPERLY SECURE YOUR WIRING.

NON-REMOVABLE CONNECTIONS

REMOVABLE CONNECTIONS

# TRACTOR - MODEL NO. CTH194 (96051003001), PRODUCT NO. 960 51 00-30

## ELECTRICAL 32




| KEY NO. | PART NO. | DESCRIPTION |
|---|---|---|
| 1 | 532 43 71-57 | Battery |
| 2 | 532 44 09-23 | Screw Hex Hd Cap M6 x 1.12MM |
| 16 | 532 17 61-38 | Switch Interlock Push-In |
| 21 | 532 40 02-52 | Harness Socket Light w/4152J |
| 22 | 532 00 41-52 | Bulb Light |
| 25 | 532 44 13-82 | Cable Starter Red |
| 26 | 532 17 51-58 | Fuse |
| 27 | 873 51 04-00 | Nut Keps Hex 1/4-20 unc |
| 28 | 532 44 13-83 | Cable, Ground Black |
| 29 | 532 40 15-45 | Switch, Seat |
| 30 | 532 19 33-50 | Switch, Ign |
| 33 | 532 41 19-35 | Key/Chain |
| 34 | 532 11 07-12 | Switch Light/Reset |
| 40 | 532 42 95-33 | Harness Ign. Dash |
| 43 | 532 19 25-07 | Solenoid |
| 46 | 532 40 17-63 | Gauge Serviceminder Hrmtr |
| 50 | 532 17 46-51 | Switch PTO |
| 55 | 817 06 05-12 | Screw Thdrol 5/16-18 x 3/4 TYTT |
| 71 | 532 44 08-20 | Harness Ign. Chassis |
| 79 | 532 17 52-42 | Socket Asm. Bulb |
| 83 | 532 43 67-74 | Nut Square M6 x 1.8.5 x 11MM |
| 99 | 817 72 04-08 | Screw 1/4-20 x 1/2 |
| 102 | 532 44 12-62 | Harness Pigtail Tex ROS Tuff Torq. |
| 105 | 532 40 75-68 | Switch Reverse |
| 107 | 532 18 03-79 | Switch Tall Bagger |
| 108 | 532 42 10-62 | Switch Snapmount |

**NOTE:** All component dimensions given in U.S. inches
1 inch = 25.4 mm

# TRACTOR - MODEL NO. CTH194 (96051003001), PRODUCT NO. 960 51 00-30

## CHASSIS AND ENCLOSURES 39




chassis-TexCrd-Gen2_TEX LT HUSQ_ 9


# TRACTOR - MODEL NO. CTH194 (96051003001), PRODUCT NO. 960 51 00-30
## CHASSIS AND ENCLOSURES 39

| KEY NO. | PART NO. | DESCRIPTION |
|---|---|---|
| 3 | 581 05 63-01 | Logo |
| 5 | 532 43 89-66 | Dash |
| 14 | 532 44 12-67 | Hood |
| 15 | 532 44 14-28 | Lens LH |
| 18 | 532 44 13-68 | Grille |
| 25 | 532 44 14-27 | Lens RH |
| 34 | 580 91 09-01 | Plate Engine |
| 36 | 817 06 05-12 | Screw 5/16-18 x 3/4 |
| 37 | 532 44 13-69 | Fender |
| 52 | 873 68 05-00 | Nut Lock 5/16-18 |
| 62 | 872 11 06-08 | Bolt Rdhd Sqnk. 3/8-16 x 1 Gr. 5 |
| 68 | 817 49 05-08 | Screw Thdrol 5/16-18 x 1/2 |
| 118 | 819 13 13-16 | Washer 13/32 x 13/16 x 16 Ga. |
| 119 | 873 68 06-00 | Nut Crownlock 3/8-16 unc |
| 130 | 532 41 63-58 | Screw #10 x 0.750 |
| 137 | 532 40 75-90 | Bumper Dash |
| 150 | 532 40 75-37 | Air Duct |
| 151 | 532 40 78-07 | Bracket Pivot |
| 152 | 532 19 95-35 | Shield Browning |
| 159 | 817 00 06-12 | Screw Hexwsh Thrd 3/8-16 x 3/4 |
| 162 | 532 14 24-32 | Screw |
| 175 | 532 19 94-72 | Crossmember |
| 176 | 532 40 07-76 | Screw 10-24 x 5/8 |
| 177 | 532 19 52-28 | Bushing Steering |
| 180 | 583 90 27-01 | Chassis |
| 182 | 532 43 67-76 | Dash Lower |
| 183 | 874 52 05-20 | Bolt 5/16-18 x 1-1/4 |
| 189 | 817 00 05-12 | Screw 5/16-18 x 3/4 |
| 191 | 532 41 65-01 | Insert Reflective RH |
| 194 | 873 90 05-00 | Nut Lock Hex Flange 5/16-18 |
| 198 | 532 44 15-52 | Indicator Deck Lift |
| 199 | 532 41 87-39 | Plate Deck Lift |
| 202 | 532 44 13-42 | Vent Side Hood RH |
| 203 | 532 44 13-43 | Vent Side Hood LH |
| 204 | 532 44 13-75 | Vent Top Hood |
| 205 | 532 44 13-44 | Skirt Hood Side RH |
| 206 | 532 44 13-45 | Skirt Hood Side LH |
| 213 | 874 76 05-12 | Bolt 5/16-18 x 3/4 |
| 214 | 532 19 91-45 | Clip Retainer Tinner |
| 217 | 532 40 91-67 | Rod Pivot |
| 218 | 532 19 63-95 | X-Piece Hood Stop |
| 228 | 532 19 51-61 | Stud Fastner |
| 234 | 532 40 47-42 | Bumper Hood |
| 235 | 532 40 61-29 | Spacer Fender |
| 236 | 873 93 05-00 | Nut Lock 5/16-18 unc |
| 238 | 532 44 13-74 | Trim |
| 239 | 532 40 48-83 | Clip |
| 282 | 532 41 41-10 | Clip Retainer |
| 283 | 532 44 72-12 | Console Deck Lift LH |
| 284 | 532 44 72-20 | Console Shft SRD RH |
| 287 | 817 60 04-06 | Screw 1/4-20 x 3/8 |
| 297 | 532 40 66-65 | Insert Reflective LH |
| 308 | 532 17 18-77 | Bolt 5/16-18 unc x 3/4 |
| 309 | 581 32 89-07 | Backplate |
| 319 | 581 31 39-06 | Lever Bagger |
| 334 | 532 44 25-37 | Bracket Engine |
| 338 | 532 43 66-40 | Bolt Shoulder |
| 339 | 532 43 66-41 | Lever Bagger Full Asm. |
| 340 | 581 32 90-01 | Door Pnt Battery tray Tex CRD |
| 342 | 532 43 59-38 | Supprt Fender |
| 343 | 532 44 07-49 | Clip |
| 344 | 532 43 89-70 | Control EZ Mulch |
| 345 | 532 44 06-39 | Knob |
| 347 | 532 44 58-32 | Hitch Tow |
| 349 | 532 43 66-06 | Fuel Tank Support Bracket |
| 366 | 581 31 46-02 | Bracket RH Front |
| 367 | 581 31 45-02 | Bracket LH Front |
| 368 | 581 42 48-01 | Full Lever |

**NOTE:** All component dimensions given in U.S. inches
1 inch = 25.4 mm

# TRACTOR - MODEL NO. CTH194 (96051003001), PRODUCT NO. 960 51 00-30

## DRIVE 40




drive-TexCrd-Gen2_K46_pedal_8


# TRACTOR - MODEL NO. CTH194 (96051003001), PRODUCT NO. 960 51 00-30
## DRIVE 40

| KEY NO. | PART NO. | DESCRIPTION |
|---|---|---|
| 1 | – – – – – – | Transaxle, Tufftorq K46DF (446488) (Order parts from transaxle manufacturer.) |
| 2 | 532 12 35-83 | Key Square |
| 6 | 532 12 40-28 | Bushing Snap |
| 17 | 532 43 62-27 | Spring Brake K46 |
| 27 | 817 49 05-28 | Screw 5/16-18 x 1-3/4 |
| 29 | 532 44 27-95 | Rod, Brake |
| 30 | 819 13 16-16 | Washer |
| 33 | 812 00 00-01 | Ring E |
| 35 | 532 40 10-31 | Rod, Brake, Park |
| 37 | 532 12 17-49 | Washer 25/32 x 1-5/8 x 16 Ga. |
| 38 | 532 16 96-13 | Nyliner Snap In |
| 42 | 532 12 48-72 | Cover, Foot Pedal |
| 49 | 872 11 06-14 | Bolt 3/8-16 unc |
| 50 | 532 19 43-27 | Idler Flat |
| 51 | 873 90 06-00 | Lock Nut 3/8-16 |
| 52 | 532 19 43-26 | Idler V-Groove |
| 56 | 532 44 27-81 | V-Belt, Drive |
| 61 | 532 44 51-51 | Pulley Transaxle K46 |
| 64 | 532 19 78-65 | Shaft Asm. Pedal Brake Control |
| 73 | 874 49 05-44 | Bolt Hex 5/16-18 x 3.75 |
| 90 | 532 44 36-05 | Keeper Belt Clutching |
| 99 | 532 44 39-47 | Rod Spring Bypass |
| 103 | 873 35 05-00 | Nut Hex Jam 5/16-18 unc |
| 116 | 873 90 05-00 | Nut Lock Hex Flange 5/16-18 |
| 125 | 817 00 05-12 | Screw 5/16-18 x 3/4 |
| 140 | 810 04 04-00 | Washer Lock Hvy Helical 1/4 |
| 143 | 817 49 05-08 | Screw 5/16-18 x 1/2 |
| 159 | 876 02 04-12 | Pin Cotter 1/8 x 3/4 |
| 160 | 532 16 94-84 | Retainer Clip |
| 161 | 532 10 57-09 | Spring, Return, Clutch |
| 163 | 532 44 27-93 | Rod Control |
| 166 | 532 42 91-64 | Nut Push |
| 167 | 532 40 52-57 | Latch Brake Parking |
| 175 | 532 42 93-59 | Shaft Asm. Shift |
| 183 | 532 13 70-57 | Spacer Axle |
| 184 | 532 44 14-07 | Handle Parking Brake |
| 185 | 872 11 06-22 | Bolt 3/8-16 unc x 2-3/4 |
| 186 | 532 19 43-21 | Spacer Retainer |
| 188 | 532 19 43-23 | Link Clutch |
| 189 | 532 43 36-11 | Bellcrank Ground Drive |
| 195 | 580 45 69-01 | Bracket Rod Brake CRD Tex |
| 196 | 817 00 06-16 | Screw |
| 197 | 585 65 86-01 | Link Clutch Anti-Rotation |
| 203 | 819 11 11-16 | Washer 11/32 x 11/16 x 16 Ga. |
| 205 | 532 12 17-48 | Washer 25/32 x 1-5/8 x 16 Ga. |
| 210 | 532 40 09-80 | Rocker Asm. Pedal Control |
| 211 | 532 12 01-83 | Bearing Nylon |
| 214 | 532 42 12-63 | Pedal Forward |
| 215 | 532 41 94-82 | Pedal Reverse |
| 221 | 532 40 31-87 | Retainer Spring Clip Handle |
| 222 | 879 21 20-10 | Washer 21/32 x 1-1/4 10 Ga. |
| 226 | 532 40 15-64 | Bracket Strap Torque |
| 227 | 817 49 05-12 | Screw Thdrol 5/16-18 x 3/4 |
| 279 | 532 44 42-83 | Link Shift |
| 280 | 819 11 10-12 | Washer 11/32 x 5/8 x 12 Ga. |
| 309 | 532 16 55-81 | Plate Fstnr Cross Shf |
| 311 | 532 16 98-45 | Washer Nylon |
| 312 | 532 16 56-14 | Hub Tapered |
| 313 | 874 78 04-16 | Bolt Hex Fin 1/4-20 unc x 1 Gd5 |
| 314 | 532 44 47-13 | Retainer Belt |
| 315 | 817 58 05-20 | Screw Thdrol 5/16-18 x 4.25 |
| 335 | 532 19 95-34 | Pulley-V-Idler.Grnd.Dr.Plated |
| 339 | 532 43 68-67 | Strap Torque K46 |
| 342 | 532 18 26-82 | Keeper Belt |
| 351 | 532 43 69-98 | Bracket 97 CRD Deck Sway |
| 352 | 532 43 56-45 | Bracket Idler |
| 355 | 532 43 56-69 | Bracket |
| 359 | 817 49 06-10 | Screw 3/8-16 x 5/8 |
| 360 | 532 44 47-14 | Nut Hex 5/16-24 |
| 362 | 532 43 68-12 | Idler Flat |
| 363 | 532 44 27-80 | Spacer |
| 364 | 532 44 30-32 | Bracket Idler |

**NOTE:** All component dimensions given in U.S. inches
1 inch = 25.4 mm

# TRACTOR - MODEL NO. CTH194 (96051003001), PRODUCT NO. 960 51 00-30

## ENGINE 24




## ENGINE 24

| KEY NO. | PART NO. | DESCRIPTION |
|---|---|---|
| 1 | – – – – – – | Engine Kohler Model No. SV590-3210 (438332) (Order parts from engine manufacturer.) |
| 2 | 532 18 86-55 | Muffler |
| 9 | 532 19 43-20 | Keeper Belt Engine |
| 11 | 587 24 16-01 | Clutch Electric |
| 12 | 532 40 50-97 | Pulley Engine |
| 15 | 581 28 99-01 | Tank Fuel |
| 18 | 532 43 02-20 | Fuel Cap |
| 20 | 532 18 38-97 | Control Throttle |
| 21 | 532 41 63-58 | Screw # 10 x 0.750 |
| 28 | 532 13 70-40 | Fuel Line |
| 29 | 532 13 71-80 | Spark Arrester Kit |
| 37 | 532 12 34-87 | Clamp Hose |
| 41 | 532 12 61-97 | Washer |
| 42 | 810 04 07-00 | Washer Lock 7/16 |
| 45 | 873 51 04-00 | Nut Keps Hex 1/4-20 unc |
| 69 | 532 18 59-09 | Gasket |
| 79 | 532 19 23-34 | Screw 5/16-18 x .75 |
| 85 | 532 17 99-53 | Bolt 7/16-20 x 3.75 Gr. |
| 87 | 537 17 18-77 | Bolt 5/16-18 unc x 3/4 w/Sems |
| 90 | 817 00 06-16 | Screw 3/8-16 x 1 |
| 92 | 817 12 06-16 | Screw 3/8-16 x 1 |
| 94 | 532 18 86-54 | Tube Exhaust |
| 96 | 819 09 14-16 | Washer 9/32 x 7/8 x 16 Ga. |
| 97 | 817 67 04-12 | Screw 1/4-20 x 3/4 |
| 102 | 817 06 05-16 | Screw 5/16-18 x 1 |
| 108 | 532 42 30-41 | Cover Pulley Engine |
| 122 | 532 42 19-22 | Extension Drain Oil |

**NOTE:** All component dimensions given in U.S. inches
1 inch = 25.4 mm

# TRACTOR - MODEL NO. CTH194 (96051003001), PRODUCT NO. 960 51 00-30

## STEERING ASSEMBLY 41



# TRACTOR - MODEL NO. CTH194 (96051003001), PRODUCT NO. 960 51 00-30


## STEERING ASSEMBLY 41

| KEY NO. | PART NO. | DESCRIPTION |
|---|---|---|
| 1 | 532 43 97-40 | Wheel, Steering |
| 2 | 532 43 68-70 | Axle Asm., Front |
| 4 | 532 43 68-73 | Spindle Asm., LH |
| 5 | 532 43 68-74 | Spindle Asm., RH |
| 6 | 532 12 49-31 | Washer Thrust 0.75 x 1.23 |
| 7 | 532 12 17-48 | Washer 25/32 x 1-5/8 x 16 Ga. |
| 8 | 812 00 00-29 | Ring, Klip #T5304-75 |
| 9 | 532 12 12-32 | Cap, Spindle |
| 13 | 532 12 17-49 | Washer 25/32 x 1-1/4 x 16 Ga. |
| 14 | 810 04 06-00 | Washer, Lock 3/8 |
| 15 | 873 54 06-00 | Nut, Crown Lock 3/8-24 unf |
| 16 | 532 44 42-13 | Shaft Steering |
| 19 | 532 19 47-29 | Plate Steering |
| 20 | 532 44 14-25 | Steering Boot |
| 21 | 532 43 77-47 | Adapter, Wheel Steering |
| 22 | 532 19 48-45 | Bushing, Strg. Blk |
| 26 | 532 43 97-43 | Insert, Wheel Steering |
| 28 | 817 00 06-12 | Screw 3/8-16 x 3/4 |
| 33 | 810 04 05-00 | Washer Lock |
| 35 | 532 44 07-70 | Gear, Sector Plate |
| 45 | 819 11 38-12 | Washer 11/32 x 2-3/8 x 12 Ga. |
| 53 | 532 18 89-67 | Washer Hardened .793 x 1.637 x .060 |
| 57 | 532 40 74-65 | Bracket Upstop |
| 58 | 532 19 47-47 | Bolt Shoulder Sector Pivot CFM |
| 59 | 532 19 47-48 | Washer Thrust Sector Steering |
| 60 | 873 97 10-00 | Nut Flange Lock 5/8-11 |
| 61 | 532 43 68-84 | Draglink, LH |
| 62 | 532 43 68-85 | Draglink, RH |
| 63 | 817 00 05-12 | Screw 5/16-18 x 3/4 |
| 64 | 532 19 98-49 | Retainer Clip Spring Steering |
| 66 | 871 02 07-48 | Bolt Hex Fghd 7/16-14 x 3 Serr |
| 67 | 532 19 47-37 | Bushing PM Front Axle |
| 68 | 873 90 07-00 | Nut Lock Flange 7/16-14 Gr. 5 |
| 69 | 532 19 91-62 | Washer 1.5 x .505 x .118 |
| 70 | 532 19 61-97 | Bracket Deck Susp. Front |
| 71 | 532 19 07-52 | Shaft Extension Steering |
| 72 | 532 42 89-82 | Bolt 5/16-18 |
| 80 | 532 00 13-70 | Washer |
| 81 | 532 43 68-87 | Link Cross RH |
| 82 | 532 43 68-77 | Pivot Bolt |
| 85 | 532 44 18-73 | Pivot RH |
| 86 | 532 44 18-72 | Pivot LH |
| 118 | 532 40 60-13 | Bushing Axle |
| 122 | 532 44 49-62 | Cap Gear Sector |

**NOTE:** All component dimensions given in U.S. inches
1 inch = 25.4 mm

# TRACTOR - MODEL NO. CTH194 (96051003001), PRODUCT NO. 960 51 00-30

## MOWER DECK 44



# TRACTOR - MODEL NO. CTH194 (96051003001), PRODUCT NO. 960 51 00-30


## MOWER DECK 44

| KEY NO. | PART NO. | DESCRIPTION |
|---|---|---|
| 1 | 580 97 33-01 | Deck Weldment |
| 2 | 532 42 30-62 | Palnut 1/4 |
| 3 | 873 90 05-00 | Nut Lock Hex Flange 5/16 - 18 |
| 5 | 817 00 05-10 | Bolt 5/16-18 |
| 11 | 532 13 77-29 | Screw Thd Roll 1/4 - 20 X 5/8 |
| 13 | 872 11 06-12 | Bolt Carr Sh 3/8 - 16 X 1-1/2 Gr. 5 |
| 14 | 532 15 60-85 | Keeper Belt Idler |
| 16 | 873 90 06-00 | Nut Lock FlG 3/8 - 16 unc |
| 17 | 532 40 02-34 | Nut Flange Lock Top |
| 18 | 532 18 76-90 | Washer Spacer Mandrel |
| 19 | 532 11 04-85 | Bearing Ball Mandrel |
| 20 | 532 17 39-84 | Screw Thread Roll |
| 23 | 817 49 06-28 | Screw Thdrol 3/8 - 16 X 1-3/4 |
| 27 | 532 44 58-86 | V-Belt Drive |
| 32 | 532 44 62-05 | Spring Drive |
| 33 | 580 79 61-01 | Mandrel Asm. Tall |
| 34 | 580 85 47-01 | Shaft Asm Mndrl N/Greaseable |
| 35 | 581 51 79-01 | Blade Mower LH |
| 36 | 532 19 30-03 | Bolt/Washer Asm 7/16 - 20 unf |
| 42 | 817 00 05-12 | Screw 5/16-18 x 3/4 |
| 43 | 532 44 32-39 | Pulley Mandrel |
| 45 | 581 65 08-01 | Mandrel Asm. Short |
| 71 | 817 67 06-08 | Screw 3/8-16 x 1/2 |
| 72 | 581 45 41-01 | Chute Upper |
| 75 | 532 13 14-94 | Pulley Idler Flat |
| 76 | 532 43 96-40 | Washout Port |
| 84 | 532 44 32-35 | Keeper Belt LH Mandrel |
| 85 | 581 51 80-01 | Blade Mower RH |
| 86 | 532 18 17-13 | Bolt 3/8-24 x 1.50 Gr. 8 |
| 87 | 810 03 06-00 | Washer Lock Hvy. 3/8 |
| 88 | 532 14 02-96 | Washer Hard |
| 91 | 819 13 20-12 | Washer 13/32 x 1-1/4 x 12 Ga. |
| 94 | 532 19 72-50 | Bracket Clutch Cable |
| 95 | 817 00 06-12 | Screw 3/8-16 x 3/4 |
| 96 | 532 40 02-71 | Spacer |
| 97 | 532 18 20-61 | Shield Idler Mower |
| 98 | 532 19 51-61 | Stud Fastener |
| 99 | 532 19 51-86 | Arm Suspension Mower Rear |
| 100 | 532 19 65-39 | Bolt Shoulder |
| 101 | 873 68 09-00 | Nut Crownlock 9/16 - 18 unc |
| 102 | 532 40 25-11 | Spacer Bearing Swing Plate |
| 104 | 581 71 40-01 | Mandrel Cover RH |
| 105 | 532 44 47-55 | Mandrel Cover LH |
| 110 | 532 41 53-56 | Gear Output |
| 111 | 532 43 69-79 | Gasket Gearcase |
| 112 | 532 44 38-52 | Shaft Gearcase Adapter |
| 113 | 532 43 85-33 | Plug Oil |
| 114 | 532 43 85-34 | Valve Relief |
| 115 | 818 03 10-16 | Screw Torx #10-24 x 1 |
| 116 | 872 11 04-14 | Bolt 1/4-20 x 1.75 Gr. 5 |
| 117 | 873 90 04-00 | Nut Hex Flange 1/4-20 unc |
| 118 | 532 44 32-32 | Arm Clutching |
| 119 | 532 43 81-66 | Gearcase Subasm |
| 120 | 532 44 32-36 | Keeper Belt RH |
| 121 | 532 43 69-85 | Washer |
| 124 | 581 65 07-01 | Non Greasable Mandrel Shaft |
| 125 | 532 44 04-20 | Bracket Idler Chassis |
| 127 | 532 19 34-06 | Bolt Shoulder 3/8-16 x 3-5/8 Gr. 5 |
| 128 | 532 17 48-73 | Wheel Gauge |
| 129 | 532 44 32-37 | Rod Anti-Sway |
| 130 | 819 13 13-12 | Washer 13/32 x 13/16 x 12 Ga. |
| 131 | 532 19 42-08 | Pin Cotter 5/16 Bow Tie Lock |
| 140 | 580 36 99-01 | Guard Sub Asm. LH |
| 141 | 532 44 77-03 | Guard Sub Asm. RH |
| 143 | 532 43 81-97 | Door Mulch |
| 144 | 532 43 58-61 | Pin Hinge |
| 145 | 532 43 79-88 | E-Ring 5/16" |
| 146 | 532 44 58-96 | Spring |
| 154 | 532 19 98-55 | Screw Thd Roll 1/4-20 x 1/2 |
| 159 | 581 48 72-02 | Plate 107 CRD LH Side |
| 160 | 581 48 71-02 | Plate 107 CRD LH Front |
| 161 | 581 48 73-02 | Plate 107 CRD RH Front |
| 162 | 581 48 74-02 | Plate 107 CRD RH Side |
| 163 | 872 11 04-06 | Bolt |
| 247 | 581 26 34-02 | Guard Steel |
| 248 | 581 26 36-02 | LH Rear Steel Guard |
| 249 | 581 26 35-02 | LH Rear Steel Guard |
| 250 | 819 11 12-12 | Washer 11/32 x 3/4 x 12 Ga. |
| - - | 580 85 60-01 | Mandrel Assembly Tall (Includes Housing (key # 33), Shaft Assembly (key # 34), And Bearing Only (key # 19) - Pulley/Nut/Washer And Blade Bolt/Washers Not Included.) |
| - - | 581 65 05-01 | Mandrel Assembly Short (Includes Housing (key # 45), Shaft Assembly (key # 124), And Bearing Only (key # 19) - Pulley/Nut/Washer And Blade Bolt/Washers Not Included.) |
| - - | 581 92 92-01 | Replacement Mower Complete |

**NOTE:** All component dimensions given in U.S. inches
1 inch = 25.4 mm

# TRACTOR - MODEL NO. CTH194 (96051003001), PRODUCT NO. 960 51 00-30

## MOWER LIFT 45





| KEY NO. | PART NO. | DESCRIPTION |
|---|---|---|
| 2 | 532 43 69-96 | Deck Lift Weldment |
| 3 | 532 19 52-31 | Lever Asm., Lift RH |
| 7 | 580 96 23-01 | Grip, Lever |
| 10 | 532 19 63-14 | Spring Torsion |
| 87 | 532 19 42-09 | Pin Cotter 7/16 Bow Tie Lock |
| 88 | 532 44 54-96 | Spring Lift Assist |
| 89 | 819 19 19-12 | Washer Clear Zinc |
| 90 | 532 19 42-08 | Pin Cotter 5/16 Bow Tie Lock |
| 91 | 532 19 51-81 | Link Lift Susp Mower Rear |
| 97 | 817 49 06-08 | Screw 3/8-16 x 1/2 |
| 98 | 532 19 52-70 | Link Lift Susp. Front Mower |
| 100 | 873 93 06-00 | Nut Center Lock 3/8-16 unc |
| 101 | 532 40 70-03 | Link Asm Lift Fixed |

**NOTE:** All component dimensions given in U.S. inches
1 inch = 25.4 mm

# TRACTOR - MODEL NO. CTH194 (96051003001), PRODUCT NO. 960 51 00-30

## SEAT ASSEMBLY 42





| KEY NO. | PART NO. | DESCRIPTION |
|---|---|---|
| 1 | 532 43 98-22 | Seat |
| 2 | 532 18 01-66 | Bracket Pivot Fender |
| 3 | 532 14 06-75 | Strap, Asm Fender |
| 6 | 873 80 06-00 | Nut, Lock w/Ins. 3/8-16 unc |
| 7 | 532 12 41-81 | Spring, Seat Cprsn |
| 8 | 532 17 18-77 | Bolt 5/16-18 unc x 3/4 w/Sems |
| 10 | 532 19 69-77 | Pan, Seat |
| 21 | 532 17 18-52 | Bolt, Shoulder 5/16-18 |

| KEY NO. | PART NO. | DESCRIPTION |
|---|---|---|
| 37 | 873 80 05-00 | Nut, Lock 5/16-18 unc |
| 40 | 532 19 76-61 | Handle Slide Seat |
| 41 | 532 19 82-00 | Spring Latch Seat |
| 43 | 874 76 06-12 | Bolt Fin Hex 3/8-16 unc x 3/4 |
| 44 | 819 13 38-12 | Washer 13/32 x 2-3/8 x 12 Ga. |

**NOTE:** All component dimensions given in U.S. inches
1 inch = 25.4 mm

# TRACTOR - MODEL NO. CTH194 (96051003001), PRODUCT NO. 960 51 00-30

## BAGGER 46



## BAGGER 46

| KEY NO. | PART NO. | DESCRIPTION |
|---|---|---|
| 1 | 532 42 86-10 | Tube Handle Bagger |
| 2 | 532 44 75-72 | |
| 3 | 532 17 48-14 | Nut Push |
| 5 | 532 44 37-62 | Frame Asm Top Bagger |
| 7 | 873 90 04-00 | Nut Hex Flange 1/4-20 unc |
| 8 | 532 44 75-75 | Cover Bagger |
| 10 | 532 44 37-55 | Frame Front |
| 19 | 532 19 42-08 | Cotter Pin 5/16 Bow Tie |
| 21 | 532 44 59-43 | Bag Asm |
| 25 | 532 44 55-28 | Latch Bagger |
| 26 | 817 49 04-12 | Screw Hexwsh Thdrol 1 14~20 x 3/4 |
| 27 | 532 44 55-29 | Grommet Rubber |
| 28 | 532 16 57-87 | Grip Handle Black |
| 42 | 532 44 04-28 | Christmas Tree Clip |
| 43 | 532 12 68-75 | Clevis Pin |
| 44 | 532 19 96-87 | Bolt 1/4-20 1.50 |
| 45 | 532 44 37-54 | Upper U Frame Weldment |
| 46 | 532 44 55-41 | Bagger Corner Close-Out RH |
| 47 | 532 44 40-79 | Bagger Corner Close-Out LH |
| 48 | 532 44 40-80 | Top Bagger Side Close-Out |
| 49 | 532 17 18-73 | Bolt Shoulder 5/16~ 18 TT |
| 50 | 532 17 18-77 | Bolt 5/16-18 unc x 3/4 W/SEMS |
| 51 | 872 11 05-06 | Bolt RDHDSQNK 5/16-18 unc x 3/4 |
| 52 | 873 80 05-00 | Nut Lock HX W/INS 5/16-18 UNC |
| 53 | 532 44 41-95 | Bracket Dump Handle |
| 54 | 532 44 72-18 | Bagger TOP Front Handle |
| 55 | 872 14 05-12 | Bolt Rdhd Sq 5/16-18UNCX1 1/2 |
| 56 | 532 42 03-06 | Pin Clevis .1830DX1.26 long |
| 58 | 532 08 51-79 | Clip Retainer PM |
| 59 | 532 44 47-63 | Bagger Spread Tube |
| 69 | 532 42 18-01 | Screw #8 |
| 70 | 817 00 06-12 | Bolt 3/8-16X3/4 |
| 83 | 873 80 06-00 | Nut Lock Hex w/Ins 3/8-16 |
| 84 | 872 11 06-08 | Bolt RDHD SQNK 3/8-16 x 1 Gr. 5 |
| 85 | 581 31 44-02 | Bracket RH Pivot |
| 86 | 581 31 43-02 | Bracket LH Pivot |
| 87 | 581 31 48-02 | Bracket RH |
| 88 | 581 31 47-02 | Bracket LH |
| 89 | 581 31 51-02 | Tube Asm. |
| 92 | 586 05 23-02 | Bracket Top Support |
| 93 | 586 05 24-02 | Bracket Support RH |
| 94 | 586 05 25-02 | Bracket Support LH |
| 95 | 817 00 05-12 | Screw 5/16-18 x 3/4 |

**NOTE:** All component dimensions given in U.S. inches
1 inch = 25.4 mm