

ILLUSTRATED PARTS LIST

MFG. ID NO. 96051009300
CUSTOMER CATALOG NO. CTH 194
PRODUCT NO. 960 51 00-93




TRACTOR - MODEL NO. CTH 194 (96051009300), PRODUCT NO. 960 51 00-93

DECALS 27



KEY NO.	PART NO.	DESCRIPTION
1	581 57 83-01	Decal Warning Sym. CE
2	581 57 97-01	Decal Warning Eng. Sym.
3	581 62 73-01	Decal, Badge
4	586 04 97-01	Decal Replacement
5	581 57 84-01	Decal, Lower Dash
8	532 44 67-75	Decal Side Panel
9	581 57 98-01	Decal Warning Service/Fire
11	581 57 91-01	Decal Mower Cut Finger Symbol
14	581 57 96-01	Decal Chassis Hot Muffler
21	532 44 11-89	Decal Belt Schematic
22	532 44 51-02	Decal, Battery
23	532 44 46-19	Decal, Bypass
24	532 44 54-93	Decal, Info/Warning
- -	532 44 14-09	Pad, Footrest Pad LH
- -	532 44 14-10	Pad, Footrest Pad RH
- -	586 18 25-20	Manual Operator's (Euro)

WHEELS AND TIRES




KEY NO.	PART NO.	DESCRIPTION
1	532 05 91-92	Cap Valve Tire
2	532 06 51-39	Stem Valve
3	532 13 83-36	Rim Front
4	532 05 99-04	Tube Front (Service Item Only)
5	532 10 62-22	Tire Front 15 x 6.0-6
6	532 12 49-57	Fitting Grease (Front Wheel Only)
7	532 12 49-59	Bearing Flange (Front Wheel Only)
8	532 17 50-39	Cap Axle Blk 1 50 x 1 00
9	532 42 05-31	Tire Rear 18 x 9.5-8
10	532 12 49-26	Tube Rear (Service Item Only)
11	532 13 83-37	Rim Asm 8" Rear
- -	532 14 43-34	Sealant, Tire (10 oz. Tube)

NOTE: All component dimensions given in U.S. inches
1 inch = 25.4 mm

TRACTOR - MODEL NO. CTH 194 (96051009300), PRODUCT NO. 960 51 00-93


SCHEMATIC 38

SCH19




IGNITION SWITCH

POSITION	CIRCUIT "MAKE"
OFF	M+G+A1
RUN/OVERRIDE	B+A1
RUN	B+A1 L+A2
START	B + S + A1



CHASSIS HARNESS
CONNECTOR (C1)
(MATING SIDE)




DASH HARNESS
CONNECTOR (C1)
(MATING SIDE)

WIRING INSULATED CLIPS
NOTE: IF WIRING INSULATED CLIPS WERE REMOVED FOR SERVICING OF UNIT, THEY SHOULD BE RE-INSTALLED TO PROPERLY SECURE YOUR WIRING.

NON-REMOVABLE CONNECTIONS

REMOVABLE CONNECTIONS

TRACTOR - MODEL NO. CTH 194 (96051009300), PRODUCT NO. 960 51 00-93
ELECTRICAL 32




KEY NO.	PART NO.	DESCRIPTION
1	532 43 71-57	Battery
2	532 44 09-23	Screw Hex Hd Cap M6 x 1.12MM
16	532 17 61-38	Switch Interlock Push-In
21	532 40 02-52	Harness Socket Light w/4152J
22	532 00 41-52	Bulb Light
25	532 44 13-82	Cable Starter Red
26	532 17 51-58	Fuse
27	873 51 04-00	Nut Keps Hex 1/4-20 unc
28	532 44 13-83	Cable, Ground Black
29	532 40 15-45	Switch, Seat
30	532 19 33-50	Switch, Ign
33	532 41 19-35	Key/Chain
34	532 11 07-12	Switch Light/Reset
40	581 58 64-01	Harness Ign. Dash
43	532 19 25-07	Solenoid
46	532 40 17-63	Gauge Serviceminder Hrmtr
50	532 17 46-51	Switch PTO
55	817 06 05-12	Screw Thdrol 5/16-18 x 3/4 TYTT
71	532 44 08-20	Harness Ign. Chassis
79	532 17 52-42	Socket Asm. Bulb
83	532 43 67-74	Nut Square M6 x 1.8.5 x 11MM
99	817 72 04-08	Screw 1/4-20 x 1/2
102	532 44 12-62	Harness Pigtail Tex ROS Tuff Torq.
105	532 40 75-68	Switch Reverse
107	532 18 03-79	Switch Tall Bagger
108	532 42 10-62	Switch Snapmount
142	583 85 78-01	Charge Port Pigtail
143	532 44 80-59	Charge Port

NOTE: All component dimensions given in U.S. inches
1 inch = 25.4 mm

TRACTOR - MODEL NO. CTH 194 (96051009300), PRODUCT NO. 960 51 00-93

CHASSIS AND ENCLOSURES 39




TRACTOR - MODEL NO. CTH 194 (96051009300), PRODUCT NO. 960 51 00-93
CHASSIS AND ENCLOSURES 39

KEY NO.	PART NO.	DESCRIPTION
3	581 05 63-01	Logo
5	585 52 98-04	Dash
14	532 44 12-67	Hood
15	532 44 14-28	Lens LH
18	532 44 13-68	Grille
25	532 44 14-27	Lens RH
34	580 91 09-01	Plate Engine
36	817 06 05-12	Screw 5/16-18 x 3/4
37	532 44 13-69	Fender
52	873 68 05-00	Nut Lock 5/16-18
62	872 11 06-08	Bolt Rdhd Sqnk. 3/8-16 x 1 Gr. 5
68	817 49 05-08	Screw Thdrol 5/16-18 x 1/2
118	819 13 13-16	Washer 13/32 x 13/16 x 16 Ga.
119	873 68 06-00	Nut Crownlock 3/8-16 unc
130	532 41 63-58	Screw #10 x 0.750
137	532 40 75-90	Bumper Dash
150	532 40 75-37	Air Duct
151	532 40 78-07	Bracket Pivot
152	532 19 95-35	Shield Browning
159	817 00 06-12	Screw Hexwsh Thrd 3/8-16 x 3/4
162	532 14 24-32	Screw
175	532 19 94-72	Crossmember
176	532 40 07-76	Screw 10-24 x 5/8
177	532 19 52-28	Bushing Steering
180	583 90 27-01	Chassis
182	532 43 67-76	Dash Lower
183	874 52 05-20	Bolt 5/16-18 x 1-1/4
189	817 00 05-12	Screw 5/16-18 x 3/4
191	532 41 65-01	Insert Reflective RH
194	873 90 05-00	Nut Lock Hex Flange 5/16-18
198	532 44 15-52	Indicator Deck Lift
199	532 41 87-39	Plate Deck Lift
202	532 44 13-42	Vent Side Hood RH
203	532 44 13-43	Vent Side Hood LH
204	532 44 13-75	Vent Top Hood
205	532 44 13-44	Skirt Hood Side RH
206	532 44 13-45	Skirt Hood Side LH
213	874 76 05-12	Bolt 5/16-18 x 3/4
214	532 19 91-45	Clip Retainer Tinner
217	532 40 91-67	Rod Pivot
218	532 19 63-95	X-Piece Hood Stop
228	532 19 51-61	Stud Fastner
234	532 40 47-42	Bumper Hood
235	532 40 61-29	Spacer Fender
236	873 93 05-00	Nut Lock 5/16-18 unc
238	532 44 13-74	Trim
239	532 40 48-83	Clip
282	532 41 41-10	Clip Retainer
283	532 44 72-12	Console Deck Lift LH
284	532 44 72-20	Console Shft SRD RH
287	817 60 04-06	Screw 1/4-20 x 3/8
297	532 40 66-65	Insert Reflective LH
308	532 17 18-77	Bolt 5/16-18 unc x 3/4
309	581 32 89-11	Backplate
319	581 31 39-06	Lever Bagger
334	532 44 25-37	Bracket Engine
338	532 43 66-40	Bolt Shoulder
339	532 43 66-41	Lever Bagger Full Asm.
340	581 32 90-01	Door Pnt Battery tray Tex CRD
342	532 43 59-38	Supprt Fender
343	532 44 07-49	Clip
344	532 43 89-70	Control EZ Mulch
345	532 44 06-39	Knob
347	532 44 28-87	Hitch Tow
349	532 43 66-06	Fuel Tank Support Bracket
366	581 31 46-02	Bracket RH Front
367	581 31 45-02	Bracket LH Front
368	581 42 48-01	Full Lever

NOTE: All component dimensions given in U.S. inches
1 inch = 25.4 mm

TRACTOR - MODEL NO. CTH 194 (96051009300), PRODUCT NO. 960 51 00-93

DRIVE 40




TRACTOR - MODEL NO. CTH 194 (96051009300), PRODUCT NO. 960 51 00-93
DRIVE 40

KEY NO.	PART NO.	DESCRIPTION
1	– – – – – –	Transaxle, Tufftorq K46DF (446488) (Order parts from transaxle manufacturer.)
2	532 12 35-83	Key Square
6	532 12 40-28	Bushing Snap
17	532 43 62-27	Spring Brake K46
27	817 49 05-28	Screw 5/16-18 x 1-3/4
29	532 44 27-95	Rod, Brake
30	819 13 16-16	Washer
33	812 00 00-01	Ring E
35	532 40 10-31	Rod, Brake, Park
37	532 12 17-49	Washer 25/32 x 1-5/8 x 16 Ga.
38	532 16 96-13	Nyliner Snap In
42	532 12 48-72	Cover, Foot Pedal
49	872 11 06-14	Bolt 3/8-16 unc
50	532 19 43-27	Idler Flat
51	873 90 06-00	Lock Nut 3/8-16
52	532 19 43-26	Idler V-Groove
56	532 44 27-81	V-Belt, Drive
61	532 44 51-51	Pulley Transaxle K46
64	532 19 78-65	Shaft Asm. Pedal Brake Control
73	874 49 05-44	Bolt Hex 5/16-18 x 3.75
90	532 44 36-05	Keeper Belt Clutching
99	532 44 39-47	Rod Spring Bypass
103	873 35 05-00	Nut Hex Jam 5/16-18 unc
116	873 90 05-00	Nut Lock Hex Flange 5/16-18
125	817 00 05-12	Screw 5/16-18 x 3/4
140	810 04 04-00	Washer Lock Hvy Helical 1/4
143	817 49 05-08	Screw 5/16-18 x 1/2
159	876 02 04-12	Pin Cotter 1/8 x 3/4
160	532 16 94-84	Retainer Clip
161	532 10 57-09	Spring, Return, Clutch
163	532 44 27-93	Rod Control
166	532 42 91-64	Nut Push
167	532 40 52-57	Latch Brake Parking
175	532 42 93-59	Shaft Asm. Shift
183	532 13 70-57	Spacer Axle
184	532 44 14-07	Handle Parking Brake
185	872 11 06-22	Bolt 3/8-16 unc x 2-3/4
186	532 19 43-21	Spacer Retainer
188	532 19 43-23	Link Clutch
189	532 43 36-11	Bellcrank Ground Drive
195	580 45 69-01	Bracket Rod Brake CRD Tex
196	817 00 06-16	Screw
197	585 65 86-01	Link Clutch
203	819 11 11-16	Washer 11/32 x 11/16 x 16 Ga.
205	532 12 17-48	Washer 25/32 x 1-5/8 x 16 Ga.
210	532 40 09-80	Rocker Asm. Pedal Control
211	532 12 01-83	Bearing Nylon
214	532 42 12-63	Pedal Forward
215	532 41 94-82	Pedal Reverse
221	532 40 31-87	Retainer Spring Clip Handle
222	879 21 20-10	Washer 21/32 x 1-1/4 10 Ga.
226	532 40 15-64	Bracket Strap Torque
227	817 49 05-12	Screw Thdrol 5/16-18 x 3/4
279	532 44 42-83	Link Shift
280	819 11 10-12	Washer 11/32 x 5/8 x 12 Ga.
309	532 16 55-81	Plate Fstnr Cross Shf
311	532 16 98-45	Washer Nylon
312	532 16 56-14	Hub Tapered
313	874 78 04-16	Bolt Hex Fin 1/4-20 unc x 1 Gd5
314	532 44 47-13	Retainer Belt
315	817 58 05-20	Screw Thdrol 5/16-18 x 4.25
335	532 19 95-34	Pulley-V-Idler.Grnd.Dr.Plated
339	532 43 68-67	Strap Torque K46
342	532 18 26-82	Keeper Belt
351	532 43 69-98	Bracket 97 CRD Deck Sway
352	532 43 56-45	Bracket Idler
355	532 43 56-69	Bracket
359	817 49 06-10	Screw 3/8-16 x 5/8
360	532 44 47-14	Nut Hex 5/16-24
362	532 43 68-12	Idler Flat
363	532 44 27-80	Spacer
364	532 44 30-32	Bracket Idler

NOTE: All component dimensions given in U.S. inches
1 inch = 25.4 mm

TRACTOR - MODEL NO. CTH 194 (96051009300), PRODUCT NO. 960 51 00-93

ENGINE 24




KEY NO.	PART NO.	DESCRIPTION
1	– – – – – –	Engine Kohler Model No. SV591-3210 (585507601) (Order parts from engine manufacturer.)
2	580 53 23-01	Muffler
9	584 90 80-01	Keeper Belt Engine
11	587 24 16-01	Clutch
12	532 40 50-97	Pulley Engine
15	581 28 99-01	Tank Fuel
18	532 43 02-20	Fuel Cap
20	532 18 38-97	Control Throttle
21	532 41 63-58	Screw # 10 x 0.750
28	532 13 70-40	Fuel Line
29	532 13 71-80	Spark Arrester Kit
37	532 12 34-87	Clamp Hose
41	532 12 61-97	Washer
42	810 04 07-00	Washer Lock 7/16
45	873 51 04-00	Nut Keps Hex 1/4-20 unc
69	532 18 59-09	Gasket
79	532 19 23-34	Screw 5/16-18 x .75
85	532 17 99-53	Bolt Hex 7/16-20 x 3.75
87	537 17 18-77	Bolt 5/16-18 unc x 3/4 w/Sems
90	817 00 06-16	Screw 3/8-16 x 1
92	817 12 06-16	Screw 3/8-16 x 1
94	583 95 53-01	Tube Exhaust
96	819 09 14-16	Washer 9/32 x 7/8 x 16 Ga.
97	817 67 04-12	Screw 1/4-20 x 3/4
102	817 06 05-16	Screw 5/16-18 x 1
108	532 42 30-41	Cover Pulley Engine
122	532 42 19-22	Extension Drain Oil

NOTE: All component dimensions given in U.S. inches
1 inch = 25.4 mm

TRACTOR - MODEL NO. CTH 194 (96051009300), PRODUCT NO. 960 51 00-93

STEERING ASSEMBLY 41




TRACTOR - MODEL NO. CTH 194 (96051009300), PRODUCT NO. 960 51 00-93
STEERING ASSEMBLY 41

KEY NO.	PART NO.	DESCRIPTION
1	532 43 97-40	Wheel, Steering
2	532 43 68-70	Axle Asm., Front
4	532 43 68-73	Spindle Asm., LH
5	532 43 68-74	Spindle Asm., RH
6	532 12 49-31	Washer Thrust 0.75 x 1.23
7	532 12 17-48	Washer 25/32 x 1-5/8 x 16 Ga.
8	812 00 00-29	Ring, Klip #T5304-75
9	532 12 12-32	Cap, Spindle
13	532 12 17-49	Washer 25/32 x 1-1/4 x 16 Ga.
14	810 04 06-00	Washer, Lock 3/8
15	873 54 06-00	Nut, Crown Lock 3/8-24 unf
16	585 86 92-02	Shaft Steering
19	532 19 47-29	Plate Steering
20	532 44 14-25	Steering Boot
21	532 43 77-47	Adapter, Wheel Steering
22	585 02 99-01	Bearing Asm.
26	532 43 97-43	Insert, Wheel Steering
27	819 21 16-16	Washer 21/32 x 1 x 16 Ga.
28	817 00 06-12	Screw 3/8-16 x 3/4
33	810 04 05-00	Washer Lock
35	532 44 07-70	Gear, Sector Plate
45	819 11 38-12	Washer 11/32 x 2-3/8 x 12 Ga.
53	532 18 89-67	Washer Hardened .793 x 1.637 x .060
57	532 40 74-65	Bracket Upstop
58	532 19 47-47	Bolt Shoulder Sector Pivot CFM
59	532 19 47-48	Washer Thrust Sector Steering
60	873 97 10-00	Nut Flange Lock 5/8-11
61	532 43 68-84	Draglink, LH
62	532 43 68-85	Draglink, RH
63	817 00 05-12	Screw 5/16-18 x 3/4
64	532 19 98-49	Retainer Clip Spring Steering
66	871 02 07-48	Bolt Hex Fghd 7/16-14 x 3 Serr
67	532 19 47-37	Bushing PM Front Axle
68	873 90 07-00	Nut Lock Flange 7/16-14 Gr. 5
69	532 19 91-62	Washer 1.5 x .505 x .118
70	532 19 61-97	Bracket Deck Susp. Front
71	532 19 07-52	Shaft Extension Steering
72	532 42 89-82	Bolt 5/16-18
75	580 68 37-01	Pinion
76	580 68 36-01	Screw
80	532 00 13-70	Washer
81	532 43 68-87	Link Cross RH
82	532 44 21-47	Pivot Bolt
85	532 44 18-73	Pivot RH
86	532 44 18-72	Pivot LH
122	532 44 49-62	Cap Gear Sector

NOTE: All component dimensions given in U.S. inches
1 inch = 25.4 mm

TRACTOR - MODEL NO. CTH 194 (96051009300), PRODUCT NO. 960 51 00-93

MOWER DECK 44



tex-deck_TexCRD-Gen2_60_r4


TRACTOR - MODEL NO. CTH 194 (96051009300), PRODUCT NO. 960 51 00-93

MOWER DECK 44

KEY NO.	PART NO.	DESCRIPTION
1	580 97 33-01	Deck Weldment
2	532 42 30-62	Palnut 1/4
3	873 90 05-00	Nut Lock Hex Flange 5/16 - 18
5	817 00 05-10	Bolt 5/16-18
11	532 13 77-29	Screw Thd Roll 1/4 - 20 X 5/8
13	872 11 06-12	Bolt Carr Sh 3/8 - 16 X 1-1/2 Gr. 5
14	532 15 60-85	Keeper Belt Idler
16	873 90 06-00	Nut Lock FlG 3/8 - 16 unc
17	532 40 02-34	Nut Flange Lock Top
19	585 32 39-01	Bearing Mandrel
20	532 17 39-84	Screw Thread Roll
23	817 49 06-28	Screw Thdrol 3/8 - 16 X 1-3/4
27	532 44 58-87	V-Belt Drive
32	532 44 62-05	Spring Drive
33	580 79 61-01	Mandrel Asm. Tall
34	587 25 65-01	Shaft Asm Mndrl
35	581 51 79-01	Blade Mower LH
42	817 00 05-12	Screw 5/16-18 x 3/4
43	532 44 32-39	Pulley Mandrel
45	581 65 08-01	Mandrel Asm. Short
47	584 30 93-01	Screw
71	817 67 06-08	Screw 3/8-16 x 1/2
72	581 45 41-02	Chute Upper
75	532 13 14-94	Pulley Idler Flat
76	532 43 96-40	Washout Port
84	532 44 32-35	Keeper Belt LH Mandrel
85	581 51 80-01	Blade Mower RH
86	532 18 17-13	Bolt 3/8-24 x 1.50 Gr. 8
87	810 03 06-00	Washer Lock Hvy. 3/8
88	532 14 02-96	Washer Hard
91	819 13 20-12	Washer 13/32 x 1-1/4 x 12 Ga.
94	532 19 72-50	Bracket Clutch Cable
95	817 00 06-12	Screw 3/8-16 x 3/4
96	532 40 02-71	Spacer
97	532 18 20-61	Shield Idler Mower
98	532 19 51-61	Stud Fastener
99	532 19 51-86	Arm Suspension Mower Rear
100	532 19 65-39	Bolt Shoulder
101	873 68 09-00	Nut Crownlock 9/16 - 18 unc
102	532 40 25-11	Spacer Bearing Swing Plate
104	581 71 40-01	Mandrel Cover RH
105	532 44 47-55	Mandrel Cover LH
110	587 93 48-01	Gear Output
111	532 43 69-79	Gasket Gearcase
112	532 44 38-52	Shaft Gearcase Adapter
113	532 43 85-33	Plug Oil
114	532 43 85-34	Valve Relief
115	818 03 10-16	Screw Torx #10-24 x 1
116	872 11 04-14	Bolt 1/4-20 x 1.75 Gr. 5
117	873 90 04-00	Nut Hex Flange 1/4-20 unc
118	532 44 32-32	Arm Clutching
119	532 43 81-66	Gearcase Subasm
120	532 44 32-36	Keeper Belt RH
121	532 43 69-85	Washer
124	581 65 07-01	Non Greasable Mandrel Shaft
125	532 44 04-20	Bracket Idler Chassis
127	532 19 34-06	Bolt Shoulder 3/8-16 x 3-5/8 Gr. 5
128	532 17 48-73	Wheel Gauge
129	532 44 32-37	Rod Anti-Sway
130	819 13 13-12	Washer 13/32 x 13/16 x 12 Ga.
131	532 19 42-08	Pin Cotter 5/16 Bow Tie Lock
136	532 43 96-39	Washout Report Remote Hook Up
137	812 00 00-29	Ring Klip
138	532 44 76-67	Hose Washout Port
139	532 44 07-42	Hose 3/8 Clamp
140	580 36 99-01	Guard Sub Asm. LH
141	532 44 77-03	Guard Sub Asm. RH
143	532 43 81-97	Door Mulch
144	532 43 58-61	Pin Hinge
145	532 43 79-88	E-Ring 5/16"
146	532 44 58-96	Spring
154	532 19 98-55	Screw Thd Roll 1/4-20 x 1/2
159	585 30 95-05	Plate 107 CRD LH Side
160	585 30 94-05	Plate 107 CRD LH Front
161	585 31 60-05	Plate 107 CRD RH Front
162	585 31 61-05	Plate 107 CRD RH Side
163	872 11 04-06	Bolt
247	581 26 34-02	Guard Steel
248	581 26 36-02	LH Rear Steel Guard
249	581 26 35-02	LH Rear Steel Guard
250	819 11 12-12	Washer 11/32 x 3/4 x 12 Ga.
- -	587 12 61-05	Mandrel Assembly Tall (Includes Housing (key # 33), Shaft Assembly (key # 34), And Bearing Only (key # 19) - Pulley/Nut/Washer And Blade Bolt/Washers Not Included.)
- -	581 65 05-01	Mandrel Assembly Short (Includes Housing (key # 45), Shaft Assembly (key # 124), And Bearing Only (key # 19) - Pulley/Nut/Washer And Blade Bolt/Washers Not Included.)
- -	581 92 92-01	Replacement Mower Complete

NOTE: All component dimensions given in U.S. inches
1 inch = 25.4 mm

TRACTOR - MODEL NO. CTH 194 (96051009300), PRODUCT NO. 960 51 00-93
MOWER LIFT 45




KEY NO.	PART NO.	DESCRIPTION
2	532 43 69-96	Deck Lift Weldment
3	532 19 52-31	Lever Asm., Lift RH
7	580 96 23-01	Grip, Lever
10	532 19 63-14	Spring Torsion
87	532 19 42-09	Pin Cotter 7/16 Bow Tie Lock
88	532 44 54-96	Spring Lift Assist
89	819 19 19-12	Washer Clear Zinc
90	532 19 42-08	Pin Cotter 5/16 Bow Tie Lock
91	532 19 51-81	Link Lift Susp Mower Rear
97	817 49 06-08	Screw 3/8-16 x 1/2
98	532 19 52-70	Link Lift Susp. Front Mower
100	873 93 06-00	Nut Center Lock 3/8-16 unc
101	532 40 70-03	Link Asm Lift Fixed

NOTE: All component dimensions given in U.S. inches
1 inch = 25.4 mm

TRACTOR - MODEL NO. CTH 194 (96051009300), PRODUCT NO. 960 51 00-93

SEAT ASSEMBLY 42




KEY NO.	PART NO.	DESCRIPTION
1	532 43 98-22	Seat
2	532 18 01-66	Bracket Pivot Fender
3	532 14 06-75	Strap, Asm Fender
6	873 80 06-00	Nut, Lock w/Ins. 3/8-16 unc
7	532 12 41-81	Spring, Seat Cprsn
8	532 17 18-77	Bolt 5/16-18 unc x 3/4 w/Sems
10	532 19 69-77	Pan, Seat
21	532 17 18-52	Bolt, Shoulder 5/16-18

KEY NO.	PART NO.	DESCRIPTION
37	873 80 05-00	Nut, Lock 5/16-18 unc
40	532 19 76-61	Handle Slide Seat
41	532 19 82-00	Spring Latch Seat
43	874 76 06-12	Bolt Fin Hex 3/8-16 unc x 3/4
44	819 13 38-12	Washer 13/32 x 2-3/8 x 12 Ga.

NOTE: All component dimensions given in U.S. inches
1 inch = 25.4 mm

TRACTOR - MODEL NO. CTH 194 (96051009300), PRODUCT NO. 960 51 00-93

BAGGER 46



Bagger_TexCRD-Gen2_6

BAGGER 46

KEY NO.	PART NO.	DESCRIPTION
1	532 42 86-10	Tube Handle Bagger
2	532 44 75-72	Applique
3	532 17 48-14	Nut Push
5	532 44 37-62	Frame Asm Top Bagger
7	873 90 04-00	Nut Hex Flange 1/4-20 unc
8	532 44 75-75	Cover Bagger
10	532 44 37-55	Frame Front
19	532 19 42-08	Cotter Pin 5/16 Bow Tie
21	532 44 59-43	Bag Asm
25	532 44 55-28	Latch Bagger
26	817 49 04-12	Screw Hexwsh Thdrol 1 14~20 x 3/4
27	532 44 55-29	Grommet Rubber
28	532 16 57-87	Grip Handle Black
42	532 44 04-28	Christmas Tree Clip
43	532 12 68-75	Clevis Pin
44	532 19 96-87	Bolt 1/4-20 1.50
45	532 44 37-54	Upper U Frame Weldment
46	532 44 55-41	Bagger Corner Close-Out RH
47	532 44 40-79	Bagger Corner Close-Out LH
48	532 44 40-80	Top Bagger Side Close-Out
49	532 17 18-73	Bolt Shoulder 5/16~ 18 TT
50	532 17 18-77	Bolt 5/16-18 unc x 3/4 W/SEMS
51	872 11 05-06	Bolt RDHDSQNK 5/16-18 unc x 3/4
52	873 80 05-00	Nut Lock HX W/INS 5/16-18 UNC
53	532 44 41-95	Bracket Dump Handle
54	532 44 72-18	Bagger TOP Front Handle
55	872 14 05-12	Bolt Rdhd Sq 5/16-18UNCX1 1/2
56	532 42 03-06	Pin Clevis .1830DX1.26 long
58	532 08 51-79	Clip Retainer PM
59	532 44 47-63	Bagger Spread Tube
69	532 42 18-01	Screw #8
70	817 00 06-12	Bolt 3/8-16X3/4
83	873 80 06-00	Nut Lock Hex w/Ins 3/8-16
84	872 11 06-08	Bolt RDHD SQNK 3/8-16 x 1 Gr. 5
85	581 31 44-02	Bracket RH Pivot
86	581 31 43-02	Bracket LH Pivot
87	581 31 48-02	Bracket RH
88	581 31 47-02	Bracket LH
89	581 31 51-04	Tube Asm.
92	586 05 23-02	Bracket Top Support
93	586 05 24-02	Bracket Support RH
94	586 05 25-02	Bracket Support LH
95	817 00 05-12	Screw 5/16-18 x 3/4

NOTE: All component dimensions given in U.S. inches
1 inch = 25.4 mm