Husqvarna

SERVICE

7

I0000029

IPL, CTH160 II, 2000-02, 106 26 23-61

HECTH1602B


CTH160 II

Spare parts
Ersatzteile
Pièces détachées
Reserve onderdelen
Repuestos
Reservdelar

REPAIR PARTS

TRACTOR- -MODEL NO. CTH160II (HECTH1602B), PRODUCT NO. 954 17 00-22

ELECTRICAL



REPAIR PARTS

TRACTOR- -MODEL NO. CTH160II (HECTH1602B), PRODUCT NO. 954 17 00-22

ELECTRICAL


KEY NO.	PART NO.	DESCRIPTION
1	532144927	Battery 12 Volt 35 AMP Wet
2	874760412	Bolt Hex Hd 1/4-20 Unc X 3/4
16	532153664	Switch Interlock Push-In
21	532166181	Harness Asm Light W/4152J
22	532004152	Bulb Light #1156
24	532124780	Cable Starter 6Ga 11" Red
25	532165987	Cable Battery Crd 56" Red
26	532166180	Fuse 15 Amp
27	873510400	Nut Keps Hex 1/4-20 Unc
28	532127725	Cable Ground 6Ga 18" Black
29	532160784	Switch Plunger Normal Op Olive
30	532163968	Switch Ignition
33	532140401	Key Ign Molded Generic
40	532170214	Harness Ign
41	871110408	Bolt Flk Fin Hex 1/4-20 Unc X 1/2
42	532131563	Cover Terminal Red
43	532145673	Solenoid
48	532140844	Adapter Ammeter Rectangular
50	532169417	Switch PTO 3PDT Black Delta
51	532140405	Ring Retainer PTO
52	532141940	Protection Wire Loop
58	532169419	Buzzer Crd
59	532166299	Switch FBI CRD
65	817211008	Screw Slftp #10-16 x 1/2 Ty-Ab
66	817490608	Screw Thdrol 3/8-16 x 1/2 Ty-Tt
70	532170245	Harness Engine
80	532146685	Harness Clutch EVX
81	532109748	Relay Asm

NOTE: All component dimensions given in U.S. inches.
1 inch = 25.4 mm.

REPAIR PARTS

TRACTOR- -MODEL NO. CTH160II (HECTH1602B), PRODUCT NO. 954 17 00-22

CHASSIS AND ENCLOSURES



REPAIR PARTS

TRACTOR- -MODEL NO. CTH160II (HECTH1602B), PRODUCT NO. 954 17 00-22

CHASSIS AND ENCLOSURES


KEY NO.	PART NO.	DESCRIPTION
1	532169831	Chassis
2	532165606	Drawbar
3	817060612	Screw 3/8-16 x .75
5	532155272	Bumper Hood/Dash
6	532155923	Saddle
8	532126471	Clip Insulator 13/32 Mtg. Hole
9	532171191	Dash
10	872140608	Bolt, Carriage 3/8-16 x 3/4
11	532155927	Panel, Dash, L.H.
13	**532172108**	Panel, Asm. Dash R.H.
15	874180512	Screw, Machine, Truss Head 5/16-18 UNC x 3/4
16	873510500	Nut
17	532165378	Hood Assembly
18	532126938	Bumper Hood
20	532156437	Plate Mtg. Battery/Fuel Tank
24	874780616	Bolt
25	819131312	Washer 13/32 x 13/16 x 12 Gauge
26	873800600	Nut
28	532165379	Grille PL
29	532165380	Lens, Grille
30	532167978	Fender
31	532165156	Bracket, Fender Support
33	532147203	Footrest, L.H.
34	532147202	Footrest, R.H.
35	872110606	Bolt
37	817490508	Screw Thdrol 5/16-18 x 1/2 TYT
38	532169834	Bracket asm Pivot Mower Rear
52	819091416	Washer 9/32 x 7/8 x 16 Ga.
53	532150067	Bracket Pick off Lt/Pl Husq
57	874780412	Bolt, Fin Hex 1/4-20 UNC x .75
68	873510400	Nut Keps Hex 1/4-20 UNC
71	873680400	Nut Crownlock 1/4-20 UNC
102	532124996	Clip Fuel Line 13/32 Mtg Hole
129	819091016	Washer 9/32 x 5/8 x 16 Ga.
134	532160219	Rod Support Hood Husq P/L
145	532156524	Rod Pivot Chassis/Hood
162	532165672	Bracket Exten Chassis Lh CRD
163	532165673	Bracket Exten Chassis Rh CRD
164	532165605	Support Battery CRD
165	532167979	Cover Battery CRD Lt
166	532164863	Screw Hwhd Hi-Lo #13-16 x 3/4
167	532165779	Support Asm. Backplate WLDMNT
168	872050412	Bolt, RDHD SHT NK 1/4-20 x 1-1/2
169	532123976	Nut, Lock 1/4 LGE FLG Gr. 5 Zinc
170	532165607	Cover, Backplate Plastic Black
171	874520640	Bolt Hex 3/8-16 x 2-1/2 Gr 5
172	819132016	Washer 13/32 x 1-1/4 x 16 Ga.
173	873510600	Nut, Keps Hex 3/8-16 UNC
174	532165939	Bracket Switch FBI CRD
175	532166212	Guard Door Rear CRD
176	532128600	Pin Hinge Pivot
177	532132796	Spring Bagger Top LH Black
178	876020312	Pin Cotter 3/32 x 3/4 Cad Zinc
179	532165942	Rod Pivot FBI CRD
180	874760516	Bolt Hex HD 5/16-18 UNC x 1
181	873680500	Nut Crownlock 5/16-18
182	532138200	Washer .385 x .625 x 11 Ga.
183	819131316	Washer 13/32 x 13/16 x 16 Ga.
184	532166139	Bracket Actuator Bagger CRD
185	532165940	Tube Lever Switch FBI CRD
186	532160793	Latch Asm Multch Bagger
187	532125004	Nut Weld .327/.304 #10-24
188	819061216	Washer #10
189	810071000	Washer Lock #10
190	871161010	Screw Truss Hd Phil 10-24 x 5/8
192	817490624	Screw Thdrol 3/8-16 x 1-1/2
193	817070412	Screw Truss 1/4-20 x 3/4
198	532168937	Nut Push
203	817490612	Screw Thdrol 3/8-16 x 3/4
207	817670508	Screw Thdrol 5/16-18 x 1/2
208	817670608	Screw Thdrol 3/8-16 x 1/2
209	817000612	Screw Hex Wsh Thdrol 3/8-16

NOTE: All component dimensions given in U.S. inches. 1 inch = 25.4 mm.

REPAIR PARTS

TRACTOR- -MODEL NO. CTH160II (HECTH1602B), PRODUCT NO. 954 17 00-22

DRIVE



REPAIR PARTS

TRACTOR- -MODEL NO. CTH160II (HECTH1602B), PRODUCT NO. 954 17 00-22

DRIVE


KEY NO.	PART NO.	DESCRIPTION
1	- - - - - - -	Transaxle Hydro Gear 331-0650 (Order parts from transaxle manufacturer)
3	532143995	Pulley Hydro 0650 Lt/CRD
8	532165619	Rod, Shift Fender Adjust Lt
9	532169992	Clutch Ele
10	876020416	Pin, Cotter 1/8 x 1
14	810040400	Washer, Lock Hvy Helical
16	873800500	Nut, Lock Hex w/Ins 5/16-18 UNC
18	874780616	Bolt Hex 3/8-16 UNC x 1 Gr.5
20	532150280	Bolt, Hex 7/16-20 x 4-1/4 5 Ga 1.38
21	532121274	Knob Duckhead 1/4-13 Unc Blk
22	532165688	Rod, Brake CRD 0650
23	532170171	Bracket asm Clutch
24	873350600	Nut
25	532106888	Spring, Rod, Brake
26	819131316	Washer 13/32 x 13/16 x 16 Ga.
27	876020412	Pin, Cotter 1/8 x 3/4
28	532145204	Rod, Parking Brake
29	532071673	Cap, Parking Brake
30	**532169592**	Bracket, Mfg. Transaxle
32	874760512	Bolt Hex 5/16-18 UNC x 3/4
33	872140506	Bolt Rdhd Sqnk 5/16-18 Unc x 3/4
34	532165496	Shaft, Asm Pedal Foot CRD
35	532120183	Bearing, Nylon
36	819211616	Washer 21/32 x 1 x 16 Ga.
37	532124963	Pin, Roll 3/16 x 1"
38	532165936	Pulley Flat Composite 3.06"
39	872110622	Bolt Rdhd 3/8-16UNC x 2-3/4 Gr. 5
40	532124965	Spacer, Split 395 x 59 Bzp
42	819131312	Washer 13/32 x 13/16 x 12 Ga.
47	532127783	Pulley, Idler, V Groove Plasitc
48	532154407	Bellcrank Clutch Grnd Drv
49	532123205	Retainer, Belt Style Spring
50	874760624	Bolt Hex Hd 3/8-16 UNC x 1-1/2
51	873680600	Nut, Crownlock 3/8-16 UNC
52	873680500	Nut Crownlock 5/16-18
53	532105710	Link, Clutch 7.66
55	532105709	Spring, Return, Clutch
56	874760620	Bolt, Hex 3/8-16 UNC x 1-1/4
57	531007549	V-Belt Kev 112" 0650 CRD
61	817060612	Screw, 3/8-16 x 3/4
62	532123533	Cover, Pedal
63	532145868	Pulley, Clutch elect EVX 1"
65	810040700	Washer
66	532154778	Keeper, Belt Engine F-Proof
71	532140158	Strap, Torque, Lh
73	532156347	Strap, Torque, Rh
74	532121199	Spacer, Split
75	532121749	Washer 25/32 x 1-1/4 x 16 Ga.
76	812000001	Ring, E
77	532123583	Key, Square
78	532121748	Washer 25/32 x 1-5/8 x 16 Ga.
81	532165585	Asm, Shaft
82	532123782	Spring, Torsion
83	819171216	Washer 17/32 x 3/4 x 16 Ga.
84	532165629	Link, Transaxle
94	532140462	Fan 7"
95	532165935	Control Asm Bypass Hydro
96	532124788	Spring, Retainer 1"
102	532141322	Washer, Bellville .50ID x 1.50D
103	873940800	Nut, Hex Jam Toplock 1/2-20 UNF
104	532140156	Arm, Control Hydro
105	871070516	Screw Cap Hex 5/16 x 18 Unc-1
144	819111016	Washer 11/32 x5/8 x 16 Ga.
145	874490540	Bolt Hex FGHD 5/16-18 x Gr 5
146	874490536	Bolt Hex FLGHD 5/16-18 x 2-1/4
147	874490524	Bolt Hex FLGHD 5/16-18 x 1-1/2
150	532165850	Bushing, Bellcrank Grnd Dr
151	819133210	Washer 13/32 x 2 x 10 Ga.
153	874760516	Bolt Hex Hd 5/16-18 Unc x 1
156	532166002	Washer Srrted 5/16ID x 1.125
157	532153236	Bolt Shoulder 5/16-18 Unc 2A
158	532165589	Bracket Shift Mount
159	532165494	Hub Tapered Flange Shift Lt
160	819292016	Washer 29/32 x 1-1/4 x 16 Ga.
161	872140406	Bolt Rdhd Sqnk 1/4-20 x 3/4 Gr 5
162	873680400	Nut Crownlock 1/4-20 Unc
163	874780416	Bolt Hex Fin 1/4-20 Unc x 1 Gr 5
164	819091010	Washer 5/8 x .281 x 10 Ga.
165	532165623	Bracket Pivot Lever
166	532166880	Screw 5/16-18 x 5/8
167	532165588	Bracket Support Shift CRD
168	532165492	Bolt Shoulder 5/16-18 x .561
169	532165580	Plate Fastening Lt
171	817490608	Screw Thdrol 3/8-16 x 1/2 Ty-Tt
172	532165587	Shaft Asm Shifter Frt CRD 0650
173	532165934	Bracket Hydro Bypass CRD
174	810090400	Washer Lock 1/4
175	532165931	Spring Bypass CRD
176	819070816	Washer 7/32 x 1/2 x 16 Ga.
177	532165932	Keeper Flat Idler 3.06" CRD
178	532165933	Keeper Belt Idler 1.88" CRD
179	532120958	Washer Sintered
180	532165630	Pulley, Idler, Flat 1.88"CRD
181	532165797	Bracket Idler Ground Drive CRD
182	532165634	Keeper Belt 2.5" Od V-Idler CRD
183	532165626	Pulley V-Idler 2.50" Od CRD
184	817490644	Screw Hexwsh Thdrol 3/8-16 x 2-3/4
185	532165541	Link Shift CRD Hydro 0650
186	532165614	Hub Tapered Round CRD
187	817490620	Screw Thdrol 3/8-16 x 1-1/4 TT
188	532110436	Bushing Snap Split Blk
202	872110612	Bolt Carr Sh 3/8-16 x 1-1/2 Gr.

NOTE: All component dimensions given in U.S. inches
1 inch = 25.4 mm

REPAIR PARTS

TRACTOR- -MODEL NO. CTH160II (HECTH1602B), PRODUCT NO. 954 17 00-22

STEERING ASSEMBLY



REPAIR PARTS

TRACTOR- -MODEL NO. CTH160II (HECTH1602B), PRODUCT NO. 954 17 00-22

STEERING ASSEMBLY

Correction:
Pos. 10 532169832


KEY NO.	PART NO.	DESCRIPTION
1	532166627	Steering Wheel
2	532165854	Axle Cast Lt Machined
3	532169840	Spindle Assembly, L.H.
4	532169839	Spindle Assembly, R.H.
5	532124931	Bearing, Race, Thrust, Hardened
6	532121748	Washer 25/32 x 1-5/8 x 16 Gauge
7	819272016	Washer 27/32 x 1-1/4 x 16 Gauge
8	812000029	Ring, Klip
10	532169632	Link, Drag
11	810040600	Washer, Lock
13	532136518	Spacer Brg Axle Front
15	532145212	Nut, Hexflange Lock
17	532156546	Shaft Assembly, Steering
18	532057079	Washer, Thrust .515 x .750 x .033
19	532160395	Support, Shaft
22	532165857	Screw Hex Wshhd Torx
23	532165851	Pittman Shaft Assembly
25	532154406	Bracket, Steering
27	532136874	Gear, Sector
29	817060612	Screw, 3/8-16 x 3/4
32	532170162	Rod, Tie
33	**819111216**	Washer 11/32 x 3/4 x 16 Ga
34	**810040500**	Washer Lock Hvy Hlcl Spr 5/16
35	**873810500**	Locknut 5/16-24 Unf
36	532155099	Bushing, Steering
37	532152927	Screw TT #I0-32 x 5 x 3/8 Flange
38	532166626	Cap Wheel Steer
39	819132411	Washer 13/32 x 1-1/2 x 11 Gauge
40	532124701	Nut Lock Center 3/8-24 Unf
41	532159945	Adaptor, Steering Wheel
42	532169634	Boot, Steering Dash P/L Mtl
43	532121749	Washer 25/32 x 1-1/4 x 16 Gauge
44	532153720	Extension Steering Non-Adjust
46	532121232	Cap, Spindle
47	532124836	Fitting, Grease
51	873800500	Nut Lock Hx W/Ins 5/16-18 UNC
54	874780520	Bolt Fin Hex 5/16-18 UNC x 1-1/4
62	532167902	Kit, Steering Assembly, Service
63	874780616	Bolt Fin Hex 3/8-16 UNC x 1 Gr. 5
65	532160367	Spacer Brace Axle
66	532154404	Bearing Arm Pittman
67	**872140618**	Bolt Rdhd Sq 3/8-16 UNC x 2-1/4
68	532169827	Brace Axle
79	819132012	Washer 13/32 x 1-1/4 x 12 Ga.
80	874950612	Bolt Hex Nylon 3/8-16 x 3/4
82	532169835	Bracket Susp Chassis Front
85	532133835	Fastener Christmas Tree

NOTE: All component dimensions given in U.S. inches.
1 inch = 25.4 mm.

REPAIR PARTS

TRACTOR- -MODEL NO. CTH160II (HECTH1602B), PRODUCT NO. 954 17 00-22

SEAT ASSEMBLY



KEY NO.	PART NO.	DESCRIPTION
1	532140840	Seat
2	532140551	Bracket Pnt Pivot Seat (blk)
5	532145006	Clip Push In Hinged
7	532124181	Spring Seat Cprsn 2 250 Blk Zi
8	817000616	Screw 3/8-16 X 1-1/2
9	819131614	Washer 13/32 X 1 X 14 Ga
10	532155925	Pan Pnt Seat (blk)
11	532166369	Knob Seat Adj. Wingnut
12	532121246	Bracket Pnt Mounting Switch
13	532121248	Bushing Snap Blk Nyl 50 Id


KEY NO.	PART NO.	DESCRIPTION
14	872050412	Bolt Rdhd Sht Nk 1/4-20x1-1/2
15	532121249	Spacer Split 28 X 88 Zinc
16	532123740	Spring Cprsn
17	532123976	Nut Lock 1/4 Lge Flg Gr 5 Zinc
21	532171852	Bolt Shoulder 5/16-18 Unc-2A
22	873800500	Nut Hex Lock w/Ins 5/16-18
24	819171912	Washer 17/32 X 1-3/16 X 12 Ga.
25	532127018	Bolt Shoulder 5/16-18 X 62

NOTE: All component dimensions given in U.S. inches.
1 inch = 25.4 mm

REPAIR PARTS


TRACTOR- -MODEL NO. CTH160II (HECTH1602B), PRODUCT NO. 954 17 00-22

DECALS



KEY NO.	PART NO.	DESCRIPTION
1	532145498	Decal Read Owner's Manual Sym
3	532170726	Decal Hood Rh
4	532170727	Decal Hood Lh
5	532170564	Decal Steering Wheel
6	532126187	Decal 100 DBA
7	532159713	Decal Panel Side B&S Logo
8	532145437	Decal Europe Stand Ce
9	532150617	Decal Fender Logo
10	532145005	Decal Bat Dan/Poi P/L Sym Wpn
11	532145494	Decal Mower Cut Finder Symbol
12	532159737	Decal Brake/Clutch Symbol Lt
13	532166959	Decal Warn Back Plate CRD
14	532159736	Decal Chassis Hot Muffler
15	532166961	Decal Oper Bag Presence CRD
16	532162598	Decal Drawbar Load Limit
17	532140837	Decal Saddle Brake Parking
20	532166960	Decal Bypass Fender CRD
21	532166286	Decal Hex Belt Sch 92 CRD
—	532138311	Decal Lift Handle
—	532171237	Pad Footrest
—	532171502	Manual Operator's (Euro)
—	532171503	Manual Operator's (Scan)

WHEELS & TIRES




KEY NO.	PART NO.	DESCRIPTION
1	532059192	Cap Value Tire
2	532065139	Stem Value
3	532106222	Tire F Ts 15 X 6 0 - 6 Service
4	532059904	Tube Inner Front #35060
5	532138336	Rim Asm 6"front Silver Service
6	532124957	Fitting Grease
7	532124959	Bearing Flange
8	532138337	Rim Asm 8"rear Silver Service
9	532138468	Tire R Ts 20 x 8-8 Service
10	532124926	Tube Rear 9 5 X 8 Service
11	532104757	Cap Axle Blk 1 50 X 1 00
- -	144334	Sealant, Tire (10 oz. tube)

NOTE: All component dimensions given in U.S. inches
1 inch = 25.4 mm

REPAIR PARTS

TRACTOR- -MODEL NO. CTH160II (HECTH1602B), PRODUCT NO. 954 17 00-22

ENGINE



OPTIONAL EQUIPMENT

Spark Arrester

REPAIR PARTS

TRACTOR- -MODEL NO. CTH160II (HECTH1602B), PRODUCT NO. 954 17 00-22

ENGINE


KEY NO.	PART NO.	DESCRIPTION
1	532148875	Control Throt
2	817720410	Screw Hex Thd Cut 1/4-20x5/8 T
3	- - - - - - - -	Engine B&S Model 303777 (Order parts from engine manufacturer)
4	532149723	Muffler Twin Lo-Twin
5	532122434	Tube, Manifold Lh
6	532122435	Tube, Manifold Rh
7	532138129	Clamp Tube Double Engine
8	532150176	Bolt 5/16-18 Unc x 3/4 w/Sems
10	532145552	Shield Heat
12	532805158	Screw Manifold vanguard B&S
13	532805024	Gasket Manifold Vanguard B&S
14	813280336	Nipple Pipe 3/8 Npt X 4-1/2"
15	813200300	Elbow Std 90 Degree 3/8-18 Npt
16	811050600	Washer Lock Ext Tooth 3/8
23	532169637	Shield Brn/Dbr Guard
25	532145996	Choke Control 37"
26	873920600	Nut, Keps 3/8-24 Unf
29	532137180	Kit Spark Arrestor (Flat Scrn)
31	532161911	Tank Fuel 2.00
32	532140527	Cap Asm Fuel W/sym Vented
33	532123487	Clamp Hose Blk
37	532137040	Line Fuel
38	- - - - - - - -	Plug Oil Drain (Order From Engine Manufacturer)
44	817490412	Screw Hexwsh Thdrol 1/4-20 x 3/4
45	**817000612**	Screw Hexwsh Thdrol 3/8-16 x 3/4
46	819091416	Washer 9/32 x 7/8 x 16 Ga.
78	817060620	Screw 3/8-16 x 1-1/4
81	**873510400**	Nut Hex 1/4-20 Unc

NOTE: All component dimensions given in U.S. inches
1 inch = 25.4 mm

REPAIR PARTS

TRACTOR- -MODEL NO. CTH160II (HECTH1602B), PRODUCT NO. 954 17 00-22

MOWER LIFT



REPAIR PARTS

TRACTOR- -MODEL NO. CTH160II (HECTH1602B), PRODUCT NO. 954 17 00-22

MOWER LIFT


KEY NO.	PART NO.	DESCRIPTION
1	532159460	Washer Asm Inner Spring W/Plunger
2	532159471	Shaft Asm. Lift
3	532105767	Pin Groove
4	812000002	E Ring #5133-62
5	819211621	Washer 21/32 x 1 x 21 Ga.
6	532120183	Bearing Nylong
7	532125631	Grip Handle Fluted
8	532124526	Button Plunger Black
11	532165829	Link Asm Lift L.H.
12	532165831	Link Asm Lift R.H.
13	532124670	Retainer Spring
15	532167253	Link Front
16	873350800	Nut Jam Hex 1/2-13 Unc
17	532130171	Trunnion Blk Zinc
18	873800800	Nut Lock w/Wsh 1/2-13 UNC
19	532139868	Arm Suspension Mower
20	532163552	Retainer Spring
23	532110807	Nut Special
24	819131016	Washer 13/32 x 5/8 x 16 Ga.
25	532124874	Spring 2-1/8"
26	532169484	Retainer Clip
27	532126971	Rod Adj Lift Zinc 7.49 Wrk Lg
28	873350600	Nut Hex Jam 3/8-16 Unc
29	532138057	Knob Inf 3/8-16 Unc Blk w/sym
30	532150233	Trunnion Infin Height
31	532140302	Bearing, Pvt. Lift. Spherical
32	873540600	Nut Crownlock 3/8-24
36	532155097	Pointer Height Indicator
37	532123935	Plug Hole Blk 1.485/1.515 Dia
38	817060516	Screw 5/16-18 x 1
40	819112410	Washer 11/32 x 1-1/2 x 10 Ga.
41	532123934	Scale Ind Height Blk
49	532145212	Nut hex Flange Lock
50	532110452	Nut Push Phos & Oil

NOTE: All component dimensions given in U.S. inches
1 inch = 25.4 mm

REPAIR PARTS

TRACTOR- -MODEL NO. CTH160II (HECTH1602B), PRODUCT NO. 954 17 00-22

MOWER



REPAIR PARTS

TRACTOR- -MODEL NO. CTH160II (HECTH1602B), PRODUCT NO. 954 17 00-22

MOWER


KEY NO.	PART NO.	DESCRIPTION
1	532169160	Housing Asm. Mower
2	872140506	Bolt Rdhd Sqnk 5/16-18 Unc x 3/4
3	532165569	Bracket Asm. S-Bar Chass 92 CRD
4	532169167	Bracket Bar Sway Deck
5	532124670	Retainer Spring
6	532165557	Bar Sway CRD
8	532850857	Bolt 3/8-24 x 1.25 Gr8 Patched
9	810030600	Washer Lock Hvy 3/8 Unplated
10	532140296	Washer Hard Blade Mower vented
11	532168720	Blade 3-1 Lh
12	532129895	Bearing Ball #6204 (Mandrel)
13	532137645	Shaft Asm. W/Lower Bearing
14	532128774	Housing Mandrel Vented (Machd)
15	532110485	Bearing Ball Mandrel
16	532168721	Blade 3-1 Rh
18	872110608	Bolt Rdhd Sqnk 3/8-16 x 1 Gr5
19	532132827	Bolt Shoulder 5/16-18 Thd Form
20	532165484	Bolt 3/8-24 x 1.25 Gr8 Ptch Lhthd
21	873680500	Nut Crown Lock 5/16-18
22	532169165	Bracket Idler Sprt RR
23	532169166	Bracket Idler Sprt RF
24	532169170	Bracket Suspension LF
25	532169171	Bracket Suspension RF
26	532165237	Brace Support Susp Frt CRD
27	532169172	Bracket Asm. Susp RR
28	532169168	Bracket Asm. Susp LR
30	532157722	Screw Thd Rolling Washer Head
31	532129963	Washer Spacer Mower Vented
32	532153535	Mandrel Pulleys
33	532137266	Nut Flg Top Lock Cntr B 9/16
34	532169174	Bracket Gauge Wheel Lf
35	532169175	Bracket Gauge Wheel Rf
36	532146763	Pulley Idler V-Groove Dim 4.25
37	819131316	Washer 11/32 x 13/16 x 16 Ga
38	532169851	Spacer Hub Arm Idler
39	872110622	Bolt Rdhd 3/8-16 UNC x 2-3/4 Gr. 5
40	873680600	Nut Crownlock 3/8-16 Unc
44	532169180	Cover Mandrel Lh
45	532169179	Cover Mandrel Rh
46	532137729	Screw Thd Roll 1/4-20 x 5/8
55	532169849	Arm Idler
61	532165945	Spring Tension Belt
68	532169178	Hex-Belt Mower
69	532165482	Shaft Asm W/Lwr Brg Rh Thd CRD
84	532156085	Keeper Belt Idler
116	532137644	Bolt Shoulder
117	532133957	Wheel Gage Donut Wide
118	873930600	Nut Centerlock 3/8-16 Unc
119	819121414	Washer 3/8 x 7/8 x 14 Ga.
124	872110612	Bolt Carr Sh 3/8-16 x 1-1/2 Gr5
128	532153390	Washer Felt
130	872110506	Bolt Rdhdsqnk 5/16-18 Unc x 3/4
131	532165661	Chute Bagger CRD 92cm/107cm
--	532130794	Mandrel Asm Service
--	532165579	Mandrel Asm CRD Lh Threads SVC
--	532170273	Deck Mower Complete

NOTE: All component dimensions given in U.S. inches
1 inch = 25.4 mm

REPAIR PARTS

TRACTOR- -MODEL NO. CTH160II (HECTH1602B), PRODUCT NO. 954 17 00-22

BAGGER




KEY NO.	PART NO.	DESCRIPTION
1	532165249	Tube Handle Bagger CRD
2	872140416	Bolt Carriage 1/4-20 X 2.0 Gr.5
3	532123976	Nut Lock 1/4 Lge Flg Gr. 5 Zinc
4	532169916	Handle Bagger w/Lev Blk CRD
5	874981024	Screw Pan Head #10-24 X 1.50 Blk
6	874981032	Screw Pan Hd
7	873401000	Nut Wiz Lock Hex Serr/Hd #10-24
8	532167980	Cover Bagger Plastic CRD
9	872140418	Bolt Carriage 1/4-20 x 2.25d x Gr.5
10	532169688	Tube Support Bagger CRD
11	532165719	Bracket Support Upper Bag CRD
12	532169685	Bracket Horiz Adj Bggr Lh CRD
13	872110606	Bolt Rdhd Sht Sqnk 3/8-16 X 3/4
14	874520640	Bolt Hex 3/8-16 X 2-1/2 Gr. 5
15	532124670	Retainer Spring
16	873900600	Nut Lock Flg 3/8-16 Unc
17	872140506	Bolt Rdhd Sht 5/16 -18 Unc X 3/4
18	819111216	Washer 11/32 x 3/4 x 16 Ga.
19	873800500	Nut Lock Hex W/Ins 5/16-18 Unc Pl
20	532169684	Bracket Horiz Adj Bggr Rh CRD
21	532165780	Bag Asm CRD

KEY NO.	PART NO.	DESCRIPTION
22	532165781	Bracket Side Bagger CRD
23	532165782	Tube Upper Bagger CRD
24	532165783	Tube Pivot Bagger CRD
25	532165784	Tube Front Bagger CRD
26	532165785	Tube Lower Bagger CRD
27	532169692	Bushing Snap Bagger CRD
28	532165787	Grip Handle Black
29	532165839	Plate Stop Bagger handle CRD
30	872140410	Bolt Carriage 1/4-20 x 1 Gr.5
31	532124788	Retainer Spring 1" Zinc/Cad
32	532126875	Rivet Rd Hd Drilled 3/8 Dia
33	532169380	Plug Mulch
34	532165570	Handle Mulcher
35	532165572	Pin Mulcher
36	819132016	Washer 13/32 x 1-1/4 x 16 Ga.
38	872010520	Bolt 5/16-18 x 2-1/2
39	532169999	Seal 26" (Long)
40	532170000	Seal 7" (Short)
41	532169683	Bracket Vert Adj Bagger CRD

NOTE: All component dimensions given in U.S. inches
1 inch = 25.4 mm


TRACTOR- -MODEL NO. CTH160II (HECTH1602B), PRODUCT NO. 954 17 00-22

SCHEMATIC




IGNITION SWITCH

POSITION	CIRCUIT	"MAKE"
OFF	M+G+A1	NONE
RUN/LIGHT	B+A1	A2+L
RUN	B+A1	NONE
START	B + S + A1	NONE



RELAY



PTO SWITCH

POSITION	CIRCUIT
OFF	C + G, B + H
ON	C + F, B + E, A + D

NON-REMOVABLE CONNECTIONS

REMOVABLE CONNECTIONS

WIRING INSULATED CLIPS

NOTE: IF WIRING INSULATED CLIPS WERE REMOVED FOR SERVICING OF UNIT, THEY SHOULD BE REPLACED TO PROPERLY SECURE YOUR WIRING.