Retrouvez cette pièce sur nhp-motoculture.fr en cliquant sur le numéro de référence

# STIGA

## GARDEN 8E (1990)

13-2126-13

**Spare parts list**
**Reservdelar**
**Repuestos**
**Ersatzteile**
**Pièces détachées**
**Reserve onderdelen**
**Catalogo ricambi**


NHP Motoculture
Cultivez votre univers

- Use ST. S.p.A. Genuine Spare Parts specified in the parts list for repair and/or replacement.
- The contents described in the parts list may change due to improvement.
- The drawings of the spare parts are only indicative And might Not represent the part in question exactly.
- The indications "right" - "left" - "front" - "rear" refer to the position of the operator when using the machine.
- When placing orders of parts for repair And/Or replacement, make sure that the illustrated parts list Is the one applying to the machine's year of manufacture, as shown on the identification plate attached to the machine.

All rights reserved. No part Of this material may be reproduced Or transmitted, in any form Or by any means, electronic Or mechanical, including photocopying, recording Or by any information storage And retrieval system, without permision in writing from ST. S.p.A.



Copyright ST. S.P.A.






Copyright ST. S.P.A.

| Réf. N° | Q.té : | Code article | Description | Articles | De | Jusqu'à |
|---|---|---|---|---|---|---|
| 1 | 1 | P000-7700-61 | Case | Please contact Peerless Customer Service | | |
| 1 | 1 | P007-7006-1A | Case | Please contact Peerless Customer Service | | |
| 2 | 1 | P000-7720-83 | Cover | Please contact Peerless Customer Service | | |
| 2 | 1 | P007-7208-3A | Cover | Please contact Peerless Customer Service | | |
| 3 | 1 | P000-7761-61 | Arbre | Please contact Peerless Customer Service | | |
| 3 | 1 | P000-7762-17 | Arbre | Please contact Peerless Customer Service | | |
| 4 | 1 | P007-7812-1A | Gear | Please contact Peerless Customer Service | | |
| 5 | 1 | P007-7812-2A | Gear | Please contact Peerless Customer Service | | |
| 6 | 1 | P007-7812-3A | Gear | Please contact Peerless Customer Service | | |
| 7 | 1 | P007-7812-4A | Gear | Please contact Peerless Customer Service | | |
| 8 | 1 | P000-7781-25 | Gear | Please contact Peerless Customer Service | | |
| 9 | 1 | P000-7842-66 | Collar | Please contact Peerless Customer Service | | |
| 10 | 1 | P000-7860-83 | Couronne | Please contact Peerless Customer Service | | |
| 11 | 1 | P000-7860-82 | Couronne | Please contact Peerless Customer Service | | |
| 12 | 1 | P000-7761-34 | Arbre | Please contact Peerless Customer Service | | |
| 13 | 1 | P000-7781-09 | Gear | Please contact Peerless Customer Service | | |
| 14 | 1 | P007-7812-6A | Gear | Please contact Peerless Customer Service | | |
| 15 | 1 | P007-7812-7A | Gear | Please contact Peerless Customer Service | | |
| 16 | 1 | P007-7812-8A | Gear | Please contact Peerless Customer Service | | |
| 17 | 1 | P007-7812-9A | Gear | Please contact Peerless Customer Service | | |
| 18 | 1 | P000-7761-35 | Arbre | Please contact Peerless Customer Service | | |
| 19 | 1 | P007-7811-3A | Bevel pinion | Please contact Peerless Customer Service | | |
| 21 | 1 | P000-7900-03 | Disque Frein | Please contact Peerless Customer Service | | |
| 23 | 1 | P000-7900-25 | Holder | Please contact Peerless Customer Service | | |
| 24 | 2 | P000-7900-06 | Brake pad | Please contact Peerless Customer Service | | |
| 25 | 1 | P000-7900-07 | Brake plate | Please contact Peerless Customer Service | | |
| 26 | 2 | P000-7860-26 | Dowel pin | Please contact Peerless Customer Service | | |
| 27 | 4 | P007-8010-5A | Douille | Please contact Peerless Customer Service | | |
| 28 | 1 | P000-7860-81 | Chaîne | Please contact Peerless Customer Service | | |
| 29 | 5 | P000-7800-72 | Rondelle | Please contact Peerless Customer Service | | |
| 30 | 2 | P000-7800-86 | Roulement À Aiguilles | Please contact Peerless Customer Service | | |
| 31 | 1 | P000-7920-72 | Anneau Ressort | Please contact Peerless Customer | | |


Copyright ST. S.P.A.

NHP
Motoculture
Cultivez votre univers






Copyright ST. S.P.A.

| Réf. N° | Q.té : | Code article | Description | Articles | De | Jusqu'à |
|---|---|---|---|---|---|---|
| 32 | 1 | P000-7920-35 | Anneau Ressort | Please contact Peerless Customer Service | | |
| 33 | 1 | P000-7801-09 | Rondelle | Please contact Peerless Customer Service | | |
| 34 | 1 | P000-7880-40 | Reataining ring | Please contact Peerless Customer Service | | |
| 35 | 1 | P000-7842-67 | Shift rod | Please contact Peerless Customer Service | | |
| 36 | 6 | P000-7920-73 | Vis | Please contact Peerless Customer Service | | |
| 36 | 8 | P000-7920-73 | Vis | Please contact Peerless Customer Service | | |
| 37 | 2 | P007-9208-9A | Clef | Please contact Peerless Customer Service | | |
| 38 | 1 | P000-7920-75 | Ecrou | Please contact Peerless Customer Service | | |
| 39 | 1 | P000-7920-76 | Rondelle | Please contact Peerless Customer Service | | |
| 40 | 1 | P000-7920-77 | Sphère | Please contact Peerless Customer Service | | |
| 41 | 1 | P000-7920-78 | Vis | Please contact Peerless Customer Service | | |
| 42 | 1 | P000-7920-79 | Ressort | Please contact Peerless Customer Service | | |
| 43 | 5 | P000-7801-08 | Rondelle | Please contact Peerless Customer Service | | |
| 44 | 1 | P000-7920-01 | O-ring | Please contact Peerless Customer Service | | |
| 45 | 1 | P000-7920-83 | Rondelle | Please contact Peerless Customer Service | | |
| 46 | 1 | P000-7860-86 | Etrier | Please contact Peerless Customer Service | | |
| 90 | 1 | P007-8806-7B | Grease | Please contact Peerless Customer Service | | |

NHP Motoculture
Cultivez votre univers


Copyright ST. S.P.A.






Copyright ST. S.P.A.

# Tecumseh Peerless Differential 100-019B

| Réf. N° | Q.té : | Code article | Description | Articles | De | Jusqu'à |
|---|---|---|---|---|---|---|
| 0 | 1 | 1134-1694-03 cliquez ici | Différentiel | | | |
| 0 | 1 | 1134-1694-04 cliquez ici | Différentiel | | | |
| 0 | 1 | 1134-1878-01 cliquez ici | Différentiel | | | |
| 1 | 1 | P000-7743-44 | Housing | | | |
| 1A | 1 | P000-7743-45 | Housing | | | |
| 1 | 1 | P000-7744-84 | Housing | | | |
| 1A | 1 | P000-7744-85 | Housing | | | |
| 2 | 1 | P000-7747-40 | Axe | | | |
| 2 | 1 | P000-7747-59 | Axe | | | |
| 2 | 1 | P000-7747-90 | Axe | | | |
| 2 | 1 | P007-7479-0A | Axe | | | |
| 3 | 1 | P000-7747-41 | Axe | | | |
| 3 | 1 | P000-7747-60 | Axe | | | |
| 3 | 1 | P000-7747-91 | Axe | | | |
| 3 | 1 | P007-7479-1A | Axe | | | |
| 4 | 2 | P000-7782-21 | Bevel gear | | | |
| 5 | 2 | P000-7780-68 | Gear | | | |
| 6 | 1 | P000-7860-40 | Pivot | | | |
| 7 | 2 | P000-7800-96 | Rondelle | | | |
| 8 | 2 | P000-7800-01 | Rondelle | | | |
| 10 | 4 | P000-7921-25 | Snap ring | | | |
| 11 | 4 | P000-7920-41 | Vis | | | |
| 13 | 1 | P000-7800-77 | Douille | | | |
| 13 | 2 | P000-7800-77 | Douille | | | |
| 13A | 1 | P000-7801-24 | Douille | | | |
| 90 | 1 | P007-8806-7B | Grease | | | |

NHP Motoculture
Cultivez votre univers


Copyright ST. S.P.A.





Cultivez votre univers


Copyright ST. S.P.A.

| Réf. N° | Q.té : | Code article | Description | Articles | De | Jusqu'à |
|---|---|---|---|---|---|---|
| 2 | 2 | 1134-1881-01 cliquez ici | Rim | | | |
| 3 | 2 | 9545-0113-00 cliquez ici | Pneu | | | |
| 4 | 4 | 9545-0500-00 cliquez ici | Soupape | | | |
| 5 | 8 | 1134-0341-01 cliquez ici | Rondelle | | | |
| 6 | 2 | 1134-1348-01 cliquez ici | Vis | | | |
| 7 | 2 | 9743-3721-32 cliquez ici | Ecrou | | | |
| 9 | 8 | 1134-9024-01 cliquez ici | Coussinet | | | |
| 10 | 2 | 1134-2648-01 cliquez ici | Rim | | | |
| 11 | 2 | 9545-0114-00 cliquez ici | Pneu | | | |
| 13 | 4 | 9650-0020-04 cliquez ici | Circlip | | | |
| 16 | 2 | 1134-1875-01 cliquez ici | Douille | | | |
| 17 | 2 | 1134-1876-01 cliquez ici | Rear Axle Mounting | | | |
| 18 | 7 | 9739-0831-22 cliquez ici | Ecrou | | | |
| 19 | 4 | 9959-0820-16 cliquez ici | Vis à tête hexagonale à bride M8x20 | | | |
| 21 | 1 | 1134-2125-01 cliquez ici | Spindle | | | |
| 21 | 1 | 1134-2125-02 cliquez ici | Spindle | | | |
| 22 | 2 | 9501-0500-00 cliquez ici | Graisseur | | | |
| 23 | 1 | 1134-2950-01 cliquez ici | Steering Kit | | | |
| 24 | 2 | 9570-0002-00 cliquez ici | Elbow Link | | | |
| 25 | 4 | 9799-0831-02 cliquez ici | Ecrou | | | |
| 26 | 1 | 1134-2803-01 cliquez ici | Steering Arm | | | |
| 27 | 1 | 9595-0258-00 cliquez ici | Locating Pin | | | |
| 28 | 1 | 9599-0067-02 cliquez ici | Split Pin | | | |
| 29 | 1 | 9699-0056-02 cliquez ici | Rondelle | | | |
| 30 | 2 | 1134-1901-01 cliquez ici | Coussinet | | | |
| 31 | 1 | 1134-1424-01 cliquez ici | Barre De Direction | | | |
| 32 | 1 | 1134-1967-01 cliquez ici | Volant | | | |
| 33 | 1 | 9595-0262-00 cliquez ici | Locating Pin | | | |
| 34 | 1 | 9699-0103-02 cliquez ici | Rondelle | | | |
| 34 | 1 | 9699-0114-02 cliquez ici | Rondelle | | | |
| 35 | 1 | 1134-1979-02 cliquez ici | Pedal | | | |
| 36 | 2 | 1134-1927-01 cliquez ici | Coussinet | | | |
| 37 | 4 | 9898-0635-12 cliquez ici | Vis | | | |
| 38 | 5 | 9739-0631-22 cliquez ici | Écrou - Tensilock à bride M& | | | |
| 39 | 1 | 1134-1937-01 cliquez ici | Levier | | | |
| 40 | 1 | 4231-0013-00 cliquez ici | Ressort | | | |
| 43 | 1 | 1134-2138-01 cliquez ici | Boulon | | | |
| 44 | 1 | 1134-2124-01 cliquez ici | Tige De Frein | | | |
| 45 | 1 | 1134-1023-00 cliquez ici | Ressort Frein | | | |
| 46 | 4 | 9699-0090-02 cliquez ici | Rondelle | | | |
| 47 | 2 | 9595-0160-00 cliquez ici | Locating Pin | | | |
| 48 | 1 | 9747-0831-02 cliquez ici | Ecrou Auto-Freinés | | | |
| 49 | 1 | 1131-1475-01 cliquez ici | Ressort | | | |
| 50 | 2 | 1134-1889-01 cliquez ici | Boulon | | | |
| 51 | 2 | 9747-0631-02 cliquez ici | Ecrou Auto-Freinés | | | |
| 52 | 1 | 1134-1931-02 cliquez ici | Barre | | | |
| 53 | 1 | 1134-2123-01 cliquez ici | Pedal | | | |
| 58 | 1 | 1134-2952-01 cliquez ici | Ressort | | | |


Copyright ST. S.P.A.





Cultivez votre univers


Copyright ST. S.P.A.

| Réf. N° | Q.té : | Code article | Description | Articles | De | Jusqu'à |
|---|---|---|---|---|---|---|
| 59 | 1 | 1134-0054-01 cliquez ici | Entretoise | | | |
| 60 | 1 | 1134-1631-02 cliquez ici | Tension Arm | | | |
| 61 | 1 | 1134-9027-01 cliquez ici | Tension Roller (Black) | | | |
| 62 | 1 | 1134-9018-01 cliquez ici | Courroie | | | |
| 63 | 1 | 9739-1031-22 cliquez ici | Ecrou | | | |
| 64 | 1 | 9997-1025-16 cliquez ici | Vis | | | |
| 65 | 1 | 1134-2661-01 cliquez ici | Guide Curroire | | | |
| 68 | 1 | 1134-0240-00 cliquez ici | Vis | | | |
| 69 | 1 | 9696-0013-01 cliquez ici | Rondelle | | | |
| 70 | 1 | 9699-0037-02 cliquez ici | Rondelle | | | |
| 71 | 1 | 1134-1849-01 cliquez ici | Poulie | | | |
| 72 | 1 | 9600-0050-00 cliquez ici | Clef | | | |
| 73 | 1 | 9650-0016-04 cliquez ici | Circlip | | | |
| 74 | 1 | 1134-1694-03 cliquez ici | Différentiel | | | |
| 75 | 1 | 1134-1691-02 cliquez ici | Couronne | | | |
| 76 | 4 | 9795-3631-02 cliquez ici | Ecrou | | | |
| 77 | 1 | 9589-0010-03 cliquez ici | Chain | | | |
| 78 | 1 | 9589-0504-00 cliquez ici | Chain Fastener | | | |
| 79 | 1 | 9500-9950-00 cliquez ici | Transmission Assy | | | |
| 80 | 1 | P000-7920-72 | Anneau Ressort | | | |
| 81 | 1 | P000-7861-15 | Couronne | | | |
| 82 | 4 | 9988-3619-16 cliquez ici | Vis | | | |
| 84 | 1 | 1134-1925-02 cliquez ici | Gear Shifter | | | |
| 85 | 1 | 1134-1981-01 cliquez ici | Shift Lock | | | |
| 86 | 1 | 9699-0060-02 cliquez ici | Rondelle | | | |
| 87 | 1 | 9987-5016-16 cliquez ici | Vis | | | |
| 90 | 1 | 1134-1736-02 cliquez ici | Moteur Poulie | | | |
| 91 | 1 | 1134-1364-02 cliquez ici | Entretoise | | | |
| 92 | 1 | 9600-0250-00 cliquez ici | Clavette | | | |
| 94 | 1 | 9987-5332-16 cliquez ici | Vis | | | |
| 100 | 1 | 9997-0616-16 cliquez ici | Vis | | | |
| 105 | 1 | 1134-2482-01 cliquez ici | Oil drain pipe assy. | | | |
| 108 | 1 | 1134-0995-01 cliquez ici | Plug | | | |
| 109 | 1 | 1134-0997-01 cliquez ici | Joint d'étanchéité | | | |
| 110 | 1 | 9404-0020-00 cliquez ici | O-ring | | | |
| 111 | 1 | 1134-2478-01 cliquez ici | Angle-oil drain pipe | | | |
| 112 | 1 | 1134-0994-01 cliquez ici | Tube Clamp | | | |
| 115 | 1 | 1134-2808-01 cliquez ici | Manche | | | |


Copyright ST. S.P.A.






Copyright ST. S.P.A.

| Réf. N° | Q.té : | Code article | Description | Articles | De | Jusqu'à |
|---|---|---|---|---|---|---|
| 6 | 1 | 1134-2827-01 cliquez ici | Floor Mat | | | |
| 7 | 1 | 1134-0443-01 cliquez ici | Ressort | | | |
| 8 | 1 | 9988-3919-16 cliquez ici | Vis | | | |
| 10 | 20 | 9739-0831-22 cliquez ici | Ecrou | | | |
| 11 | 9 | 9959-0820-16 cliquez ici | Vis à tête hexagonale à bride M8x20 | | | |
| 12A | 1 | 1134-0800-06 cliquez ici | Seat Sears Sa 1216 (9407-0003-01) 20 | | | |
| 12B | 1 | 1134-3238-01 cliquez ici | Seat | | | |
| 13 | 1 | 1134-2119-01 cliquez ici | Seat bracket | | | |
| 14 | 1 | 1134-1038-00 cliquez ici | Attaching plate | | | |
| 15 | 4 | 9699-0028-02 cliquez ici | Rondelle | | | |
| 16 | 1 | 1131-1455-00 cliquez ici | Câble De Batterie (-) | | | |
| 17 | 1 | 1134-0234-01 cliquez ici | Câble De Batterie (+) | | | |
| 18 | 1 | 1134-1174-02 cliquez ici | Durée de la batterie | | | |
| 19 | 2 | 9942-0612-16 cliquez ici | Vis | | | |
| 20 | 1 | 1134-2333-01 cliquez ici | Battery Pad | | | |
| 21 | 1 | 9400-0064-02 cliquez ici | Support Batterie | | | |
| 22 | 1 | 9400-0086-00 cliquez ici | Batterie | | | |
| 23 | 1 | 1134-1995-01 cliquez ici | Faisceau de câbles | | | |
| 24 | 1 | 1134-1814-01 cliquez ici | Starter Switch Assy. | | | |
| 25 | 1 | 1134-2848-01 cliquez ici | Clef A Demarrage | | | |
| 27 | 1 | 9400-0170-00 cliquez ici | Cable Connection | | | |
| 28 | 2 | 9699-0099-02 cliquez ici | Rondelle | | | |
| 29 | 2 | 9739-0531-22 cliquez ici | Ecrou | | | |
| 30 | 2 | 9997-0512-16 cliquez ici | Vis | | | |
| 31 | 1 | 1134-2167-01 cliquez ici | Cable | | | |
| 34 | 1 | 9400-0105-01 cliquez ici | Interrupteur | | | |
| 36 | 2 | 1134-1874-01 cliquez ici | Rear Mudguard, Yellow | | | |
| 37 | 10 | 9942-0816-16 cliquez ici | Vis | | | |
| 38 | 1 | 9959-0820-16 cliquez ici | Vis à tête hexagonale à bride M8x20 | | | |
| 38 | 1 | 9959-0825-16 cliquez ici | Vis à tête hexagonale à bride M8x25 | | | |
| 40 | 2 | 1134-2075-01 cliquez ici | Suspension plate | | | |
| 41 | 1 | 1134-1909-01 cliquez ici | Brake guard | | | |
| 42 | 1 | 1134-1975-08 cliquez ici | Câble Accélérateur | | | |
| 43 | 1 | 9403-0035-10 cliquez ici | Pommeau | | | |
| 44 | 2 | 9849-8013-16 cliquez ici | Vis | | | |
| 45 | 1 | 1134-1916-01 cliquez ici | Stop Plate | | | |
| 47 | 1 | 1134-1830-03 cliquez ici | Butée Chaîne | | | |
| 48 | 1 | 1134-1887-01 cliquez ici | Towing Eyelet | | | |
| 49 | 1 | 1134-2128-01 cliquez ici | Bumper | | | |
| 50 | 4 | 9997-0850-16 cliquez ici | Vis | | | |
| 52 | 6 | 9988-3619-16 cliquez ici | Vis | | | |
| 53 | 4 | 9997-0835-12 cliquez ici | Vis | | | |
| 54 | 1 | 1134-2962-01 cliquez ici | Solenoid | | | |
| 55 | 1 | 1134-2947-01 cliquez ici | Cable Connection | | | |
| 56 | 2 | 9794-5131-02 cliquez ici | Ecrou | | | |
| 59 | 1 | 1134-2177-01 cliquez ici | Protection shield | | | |


Copyright ST. S.P.A.






Copyright ST. S.P.A.

| Réf. N° | Q.té : | Code article | Description | Articles | De | Jusqu'à |
|---|---|---|---|---|---|---|
| 62 | 1 | 9849-8013-16 cliquez ici | Vis | | | |
| 63 | 1 | 1134-2145-01 cliquez ici | Bearing Box Assy. | | | |
| 64 | 1 | 9815-8013-16 cliquez ici | Vis | | | |
| 65 | 1 | 1134-2238-01 cliquez ici | Attachment | | | |
| 66 | 1 | 1134-2239-01 cliquez ici | Rubber guard | | | |
| 70 | 1 | 1134-2310-01 cliquez ici | Guard Cap | | | |
| 71 | 2 | 1134-3300-01 cliquez ici | Battery Acid | | | |
| 72 | 1 | 1134-2434-01 cliquez ici | Strenghtening plate | | | |
| 73 | 1 | 9579-0003-00 cliquez ici | Fixation De Cable | | | |
| 74 | 1 | 9942-0512-16 cliquez ici | Vis | | | |
| 77 | 2 | 9942-0820-16 cliquez ici | Vis | | | |
| 80 | 4 | 9699-0090-02 cliquez ici | Rondelle | | | |
| 99 | 1 | 1134-2431-01 cliquez ici | Ens. Etiquette | | | |

NHP Motoculture
Cultivez votre univers


Copyright ST. S.P.A.





Copyright ST. S.P.A.

# Mower Deck Blade

| Réf. N° | Q.té : | Code article | Description | Articles | De | Jusqu'à |
|---|---|---|---|---|---|---|
| 0 | 1 | 13-2915-92 cliquez ici | Mower deck assy | | | |
| 1 | 1 | 1134-2061-01 cliquez ici | Lame (65B) | | | |
| 2 | 2 | 9991-1024-19 cliquez ici | Vis | | | |
| 3 | 2 | 9959-0830-16 cliquez ici | Vis | | | |
| 4 | 1 | 1134-2082-01 cliquez ici | Guide-Lame | | | |
| 7 | 1 | 1134-2147-01 cliquez ici | Roulement | | | |
| 8 | 1 | 9549-0014-00 cliquez ici | Roulement À Billes | | | |
| 9 | 1 | 9549-0027-00 cliquez ici | Roulement À Billes | | | |
| 10 | 1 | 1134-2083-01 cliquez ici | Arbre Lame | | | |
| 12 | 11 | 9739-0831-22 cliquez ici | Ecrou | | | |
| 13 | 2 | 1134-0323-00 cliquez ici | Clavette | Inkl. pos 4, 10 - 11 | | |
| 14 | 1 | 1134-1998-01 cliquez ici | Protection Courroie | | | |
| 15 | 3 | 9699-0062-02 cliquez ici | Rondelle | | | |
| 16 | 2 | 9959-0825-16 cliquez ici | Vis à tête hexagonale à bride M8x25 | | | |
| 19 | 1 | 1134-2000-01 cliquez ici | Poulie | | | |
| 20 | 1 | 9699-0030-02 cliquez ici | Rondelle | | | |
| 21 | 7 | 9959-0816-16 cliquez ici | Vis | Inkl. pos 2 | | |
| 22 | 1 | 1134-9017-01 cliquez ici | Courroie | | | |
| 25 | 1 | 1134-9027-01 cliquez ici | Tension Roller (Black) | | | |
| 26 | 1 | 1134-0054-00 cliquez ici | Entretoise | | | |
| 27 | 1 | 1134-1795-01 cliquez ici | Belt Stirrup | | | |
| 28 | 1 | 9699-0035-02 cliquez ici | Rondelle | | | |
| 29 | 1 | 9739-1031-22 cliquez ici | Ecrou | | | |
| 32 | 1 | 9997-1040-12 cliquez ici | Vis | | | |
| 33 | 1 | 1134-1999-01 cliquez ici | Brake Pad | | | |
| 34 | 1 | 9699-0028-02 cliquez ici | Rondelle | | | |
| 37 | 1 | 1134-2079-01 cliquez ici | Stop | | | |
| 38 | 1 | 1134-2092-01 cliquez ici | Levier | | | |
| 39 | 1 | 9403-0110-01 cliquez ici | Handle | | | |
| 40 | 1 | 1134-1023-00 cliquez ici | Ressort Frein | | | |
| 41 | 1 | 9747-0831-02 cliquez ici | Ecrou Auto-Freinés | | | |
| 42 | 1 | 9997-0865-12 cliquez ici | Vis | | | |
| 45 | 1 | 1134-2094-01 cliquez ici | Turning Plate | | | |
| 46 | 2 | 1111-0158-00 cliquez ici | Douille | | | |
| 47 | 1 | 1134-0357-02 cliquez ici | Ressort | | | |
| 48 | 1 | 1131-1475-01 cliquez ici | Ressort | | | |
| 49 | 1 | 9675-0018-02 cliquez ici | Starlock | | | |
| 50 | 1 | 1134-2095-01 cliquez ici | Tensioning Arm | | | |

NHP Motoculture
Cultivez votre univers


Copyright ST. S.P.A.