





Pièces de rechange Spare parts list

400011****






**MOTOFAUCHEUSE
MOTOR MOWER**







40_Châssis avant génériques FIRST _ Default:









40_Guidon First'Plorer_Feuille1




OPTION



OPTION




4002061301: ROUGE RAL3001 / RED RAL3001
 4002062001: VERT RAL6029 / GREEN RAL6029
 4002062301: BLEU P301 / BLUE P301
 4002062401: ORANGE RAL2004/ ORANGE RAL2004
 4002064201: JAUNE RAL1003 / YELLOW RAL1003
 4002065701: BLEU RAL5010 / BLUE RAL5010




0503000049

0300702001



0503010328: ROUGE RAL3001 / RED RAL3001
 0503010330: BLEU RAL5010 / BLUE RAL5010
 0503010332: ORANGE RAL2009 / ORANGE RAL2009
 0503010341: JAUNE RAL 1003 / YELLOW RAL 1003
 0503010337: VERT RAL 6069 / GREEN RAL 6069



0503010329: ROUGE RAL3001 / RED RAL3001
 0503010331: BLEU RAL5010 / BLUE RAL5010
 0503010333: ORANGE RAL2009 / ORANGE RAL2009
 0503010334: JAUNE RAL1003 / YELLOW RAL1003
 0503010338: VERT RAL 6069 / GREEN RAL 6069

0300702001