




Pièces de rechange Spare parts list

500003****



*DEBROUSSAILLEUSE
GRASS CUTTER*




0340040002: Bleu P301 / Blue P301

0340040018: Noir RAL9005 / Black RAL9005

0340040016: Jaune RAL1028 / Yellow RAL1028

0340040008: Orange RAL2009 / Orange RAL2009

0340040010: Rouge RAL 3001 / Red RAL3001



5002030305: Noir RAL9005 / Black RAL9005

5002031305: Rouge RAL3001 / Red RAL3001

5002035705: Bleu RAL5010 / Blue RAL5010

5002032405: Orange RAL2004 / Orange RAL2004

